

SH915/SW916
Digital Projector
User Manual

Table of contents

Important safety
instructions 3
Introduction7
Projector features7
Shipping contents9
Projector exterior view10
Controls and functions12
Positioning your
projector 20
Choosing a location20
Obtaining a preferred projected image
size21
Connection 23
Connecting video source devices24
Playing sound through the projector25 $$
Operation 26
Operation
_
Starting up the projector26
Starting up the projector

16
Adjusting the sound46
Jsing the test pattern47
Jsing the teaching templates48
Jsing the quick install48
Controlling the projector through a LAN environment49
Jsing the Web Control Lock58
Displaying image through Q Presenter 58
Using the Projection Login Code 61
Jsing the broadcassting function 62
Remote Desktop Control through Q
Presenter63
Presenting From a USB Reader 64
Shutting down the projector65
Menu operation66
Maintenance79
Care of the projector79
amp information80
Troubleshooting 86
Specifications87
Projector specifications87
Dimensions 88
Fiming chart89
Warranty and Copyright

information..

Important safety instructions

Your projector is designed and tested to meet the latest standards for safety of information technology equipment. However, to ensure safe use of this product, it is important that you follow the instructions mentioned in this manual and marked on the product.

Safety Instructions

 Please read this manual before you operate your projector. Save it for future reference.



 Do not look straight at the projector lens during operation. The intense light beam may damage your eyes.



3. Refer servicing to qualified service personnel.



 Always open the lens shutter or remove the lens cap when the projector lamp is on.



5. In some countries, the line voltage is NOT stable. This projector is designed to operate safely within a mains voltage between 100 to 240 volts AC, but could fail if power cuts or surges of ±10 volts occur. In areas where the mains voltage may fluctuate or cut out, it is recommended that you connect your projector through a power stabilizer, surge protector or uninterruptible power supply (UPS).



 Do not block the projection lens with any objects when the projector is under operation as this could cause the objects to become heated and deformed or even cause a fire. To temporarily turn off the lamp, press ECO BLANK on the projector or remote control.



Safety Instructions (Continued)

7. The lamp becomes extremely hot during operation. Allow the projector to cool for approximately 45 minutes prior to removing the lamp assembly for replacement.



 Do not operate lamps beyond the rated lamp life. Excessive operation of lamps beyond the rated life could cause them to break on rare occasions.



 Never replace the lamp assembly or any electronic components unless the projector is unplugged.



 Do not place this product on an unstable cart, stand, or table. The product may fall, sustaining serious damage.



11. Do not attempt to disassemble this projector. There are dangerous high voltages inside which may cause death if you should come into contact with live parts. The only user serviceable part is the lamp which has its own removable cover. Under no circumstances should you ever undo or remove any other covers. Refer servicing only to suitably qualified professional service personnel.




 When the projector is under operation, you may sense some heated air and odor from its ventilation grill. It is a normal phenomenon and not a product defect.

Safety Instructions (Continued)

- Do not place this projector in any of the following environments.
 - Space that is poorly ventilated or confined. Allow at least 50 cm clearance from walls and free flow of air around the projector.
 - Locations where temperatures may become excessively high, such as the inside of a car with all windows rolled up.
 - Locations where excessive humidity, dust, or cigarette smoke may contaminate optical components, shortening the projector's life span and darkening the image.



- Locations near fire alarms
- Locations with an ambient temperature above 40°C / 104°F
- Locations where the altitudes are higher than 3000 m (10000 feet).



- 14. Do not block the ventilation holes.
 - Do not place this projector on a blanket, bedding or any other soft surface.
 - Do not cover this projector with a cloth or any other item.
 - Do not place inflammables near the projector.




If the ventilation holes are seriously obstructed, overheating inside the projector may result in a fire.

- Always place the projector on a level, horizontal surface during operation.
 - Do not use if tilted at an angle of more than 10 degrees left to right, nor at angle of more than 15 degrees front to back.
 Using the projector when it is not fully horizontal may cause a malfunction of, or damage to, the lamp.



16. Do not stand the projector on end vertically. Doing so may cause the projector to fall over, causing injury or resulting in damage to the projector.



Safety Instructions (Continued)

17. Do not step on the projector or place any objects upon it. Besides probable physical damage to the projector, doing so may result in accidents and possible injury.



18. Do not place liquids near or on the projector. Liquids spilled into the projector may cause it to fail. If the projector does become wet, disconnect it from the power supply's wall socket and call BenQ to have the projector serviced.



 This product is capable of displaying inverted images for ceiling mount installation.



Use only BenQ's Ceiling Mount Kit for mounting the projector and ensure it is securely installed.





Ceiling mounting the projector

We want you to have a pleasant experience using your BenQ projector, so we need to bring this safety matter to your attention to prevent possible damage to person and property.

If you intend to mount your projector on the ceiling, we strongly recommend that you use a proper fitting BenQ projector ceiling mount kit and that you ensure it is securely and safely installed.

If you use a non-BenQ brand projector ceiling mount kit, there is a safety risk that the projector may fall from the ceiling due to an improper attachment through the use of the wrong gauge or length screws. You can purchase a BenQ projector ceiling mount kit from the place you purchased your BenQ projector. BenQ recommends that you also purchase a separate Kensington lock compatible security cable and attach it securely to both the Kensington lock slot on the projector and the base of the ceiling mount bracket. This will perform the secondary role of restraining the projector should its attachment to the mounting bracket become loose.



Hg - Lamp contains mercury. Manage in accordance with local disposal laws. See www.lamprecycle.org.

Introduction

Projector features

The projector offers the following features

SmartEco™ starts your dynamic power saving

The SmartEco[™] technology offers a new way of operating the projector lamp system and saves lamp power up to 70% depending on the content brightness level.

Longer lamp life with SmartEco[™] technology

The SmartEco™ technology lowers the power consumption and increases the lamp life when SmartEco mode is selected.

ECO BLANK saves 70% of lamp power (available in SH915)

By pressing the **ECO BLANK** button to hide the image and immediately lower 70% of the lamp power at the same time.

• ECO BLANK saves 50% of lamp power (available in SW916)

By pressing the **ECO BLANK** button to hide the image and immediately lower 50% of the lamp power at the same time.

- USB MINI-B jack to display computer signal through a USB cable.
- USB TYPE A jack to present images stored on a USB flash driver.
- · Less than 0.5W in standby condition

Less than 0.5W power consumption under standby mode.

Filter Free

Filter free design to lower maintenance and operating costs.

Network Control

Integrated RJ45 connector for wired network control allowing management of projector status from a computer using a web browser.

Crestron RoomView[®], PJ Link and AMX supported

The projector supports Crestron eControl and RoomView, PJ Link and AMX allowing you to control and manage equipment from a remote computer via LAN connection.

One-key auto-adjustment

Pressing AUTO on the keypad or remote control to show the best picture quality immediately.

Built-in 5W speaker(s)

Built-in 5W speaker(s) providing mixed mono audio when an audio input is connected.

Quick Cooling, Auto Power Off, Signal Power On, Direct Power On
 Quick Cooling function speeds up the cooling process when turning off the
 projector. Auto Power Off function allows the projector to turn off automatically if
 no input signal is detected after a set period of time. Signal Power On function turns
 on your projector automatically once detecting the signal input and Direct Power On
 boots up the projector automatically when the power is connected.

Instant Restart

Selectable **Instant Restart** function enables you to restart the projector immediately within 90 seconds after turning it off.

3D Function supported

Various 3D formats make the 3D function more flexible. By presenting the depth of the images, you can wear BenQ 3D glasses to enjoy the 3D movies, videos and sporting events in a more realistic way.

Introduction 7

· ج	The apparent brightness of the projected image will vary depending on the ambient lighting conditions.
	selected input signal contrast/brightness settings, and is directly proportional to projection distance.

The lamp brightness will decline over time and may vary within the lamp manufacturers specifications. This
is normal and expected behavior.

Shipping contents

Carefully unpack and verify that you have all of the items shown below. If any of these items are missing, please contact your place of purchase.

Standard accessories

The supplied accessories will be suitable for your region, and may differ from those illustrated.





Projector

Remote control with battery





Power cord

VGA cable







Quick start guide

User manual CD

Warranty card*

Optional accessories

1. Spare lamp kit


3. Soft Carry Case

2. Ceiling mount kit


*The warranty card is only supplied in some specific regions. Please consult your dealer for detailed information.

Introduction 9

Projector exterior view




- I. Lamp compartment cover
- 2. Quick-release button
- 3. Projection lens
- 4. Focus ring and Zoom ring
- External control panel (See "Projector" on page 12 for details.)
- 6. Vent (cool air intake)
- 7. Front IR remote sensor
- 8. Lens cap & string



- 9. HDMI I input jack
- 10. HDMI 2 input jack
- 11. RGB signal output jack
- 12. COMPUTER-I input jack
- 13. COMPUTRR-2 input jack
- 14. RJ45 LAN input jack
- 15. Audio (L/R) input jack
- 16. USB Type-A ports
- 17. USB Mini-B port
- 18. Kensington anti-theft lock slot
- 19. Rear adjuster foot
- 20. Audio speaker
- 21. Rear IR remote sensor
- 22. VIDEO input jack
- 23. S-VIDEO input jack
- 24. Audio input/output jack
- 25. I2V TRIGGER
- 26. Quick-release foot
- 27. USB Type B port
- 28. RS-232 control port
- 29. AC power cord inlet

- 30. Ceiling mount holes
- 31. Rear adjuster foot




Introduction II


Controls and functions

Projector

SH915



SW916



I. FOCUS/ZOOM Ring

Used to adjust the projected image appearance. See "Fine-tuning the image size and clarity" on page 28 for details.

2. Keystone/Arrow keys (▼/▲ Up)

Manually corrects distorted images resulting from an angled projection.

See "Correcting keystone" on page 28 for details.

3. MENU/EXIT

Turns on the On-Screen Display (OSD) menu. Goes back to previous OSD menu, exits and saves menu settings. See "Using the menus" on page 33 for details.

4. MODE/ENTER

Selects an available picture setup mode. See "Selecting a picture mode" on page 40 for details.

Enacts the selected On-Screen Display (OSD) menu item. See "Using the menus" on page 33 for details.

Decreases volume. See "Adjusting the sound level" on page 47 for details. (available in SH915)

5. Keystone/Arrow keys () / ◀ Left)

Manually correct distorted images resulting from an angled projection. See "Correcting keystone" on page 28 for detail. (available in SW916)

6. ECO BLANK

Used to hide the screen picture. See "Hiding the image" on page 45 for details.

(l) POWER

Toggles the projector between standby mode and on.

See "Starting up the projector" on page 26 and "Shutting down the projector" on page 65 for details.

8. POWER indicator light

Lights up or flashes when the projector is under operation. See "Indicators" on page 85 for details.

9. AUTO

Automatically determines the best picture timings for the displayed image. See "Auto-adjusting the image" on page 27 for details

10. ► Right/ •(*) Increase volume level

Increases volume. See "Adjusting the sound level" on page 47 for details. (available in SH915)

When the On-Screen Display (OSD) menu is activated, the #2, #5, #10, and #12 keys are used as directional arrows to select the desired menu items and to make adjustments. See "Using the menus" on page 33 for details.

10. Keystone/Arrow keys (/► Right)

Manually correct distorted images resulting from an angled projection. See "Correcting keystone" on page 28 for detail. (available in SW916)
When the On-Screen Display (OSD) menu is activated, the #2, #5, #10, and #12 keys are used as directional arrows to select the desired menu items and to make adjustments. See "Using the menus" on page 33 for details.

II. SOURCE

Displays the source selection bar. See "Switching input signal" on page 37 for details.

12. Keystone/Arrow keys (▲/▼ Down)

Manually corrects distorted images resulting from an angled projection. See "Correcting keystone" on page 28 for details.

13. LAMP indicator light

Indicates the status of the lamp. Lights up or flashes when the lamp has developed a problem. See "Indicators" on page 85 for details.


14. TEMPerature indicator light

Lights up red if the projector's temperature becomes too high. See "Indicators" on page 85 for details.

Introduction 13

Remote Control

SH915



I. ON/ OFF

Toggles the projector between standby mode and on.

2. Source selection buttons

Selects an input source for display.

Keystone/Arrow keys (▼/▲ Up, ▲/▼ Down)

Manually corrects distorted images resulting from an angled projection.

4. MENU/EXIT

Turns on the On-Screen Display (OSD) menu. Goes back to previous OSD menu, exits and saves menu settings.

5. **◀** Left/ **邶**

Decreases the projector volume.

6. ECO BLANK

Used to hide the screen picture.

LASER (No available in Japan region) Emits visible laser pointer light for presentation purposes.

8. ZOOM+/ZOOM-

Magnifies or reduces the projected picture size.

9. ASPECT

Selects the display aspect ratio.

10. FREEZE

Freezes the projected image.

II. NETWORK SETTING

Displays the **Network Settings** OSD menu.

12. Numeric buttons

Enters numbers in network settings.



Numeric buttons 1, 2, 3, 4 cannot be pressed when asked to enter password.

13. NETWORK

Selects Network Display as the input signal source.

14. AUTO

Automatically determines the best picture timings for the displayed image.

15. ► Right/ •••)

Increases the projector volume.

When the On-Screen Display (OSD) menu is activated, the #3, #5, and #15 keys are used as directional arrows to select the desired menu items and to make adjustments.

16. MODE/ENTER

Selects an available picture setup mode. Activates the selected On-Screen Display (OSD) menu item.

17. SOURCE

Displays the source selection bar.

18. PAGE +/PAGE -

Operate your display software program (on a connected PC) which responds to page up/down commands (like Microsoft PowerPoint).

19. MIC/VOL +/MIC/VOL -

The function is not available on this projector.

20. MUTE

Toggles projector audio between on and off.

21. SMART ECO

Switch the lamp mode between Eco/ Normal and SmartEco.

22. QUICK INSTALL ("TEST" is for lapan region)

Displays the ${\bf Quick\ Install\ OSD\ menu.}$

Operating the LASER pointer

The Laser Pointer is a presentation aid for professionals. It emits a beam of red light when you press it.

The laser beam is visible. It is necessary to press and hold LASER for continuous output.






Do not look into the laser light window or shine the laser light beam on yourself or others. See the warning messages on the back of the remote control prior to using it.

The laser pointer is not a toy. Parents should be mindful of the dangers of laser energy and keep this remote control out of the reach of children.

Introduction 15

SW916



I. ON / OFF

Toggles the projector between standby mode and on.

- Source selection buttons Selects an input source for display.
- Manually corrects distorted images resulting from an angled projection.

 When the On-Screen Display (OSD) menu is activated, the #3 keys are used as a directional arrows to select the desire

4. MENU/EXIT

3.

Turns on the On-Screen Display (OSD) menu. Goes back to previous OSD menu, exits and saves menu settings.

menu items and to make adjustments.

5. ECO BLANK

Used to hide the screen picture.

- LASER (No available in Japan region)
 Emits visible laser pointer light for presentation purposes.
- QUICK INSTALL ("TEST" is for Japan region)
 Displays the Quick Install OSD menu.
- 8. FREEZE

Freezes the projected image.

- ASPECT
 Selects the display aspect ratio.
- IO. PIP

The function is not available on this projector.

II. NETWORK SETTING

Displays the Network Settings OSD menu.

12. Numeric buttons

Enters numbers in network settings.

Numeric buttons I, 2, 3, 4 cannot be pressed when asked to enter password.

13. AUTO

Automatically determines the best picture timings for the displayed image.

14. MODE/ENTER

Selects an available picture setup mode. Activates the selected On-Screen Display (OSD) menu item.

15. SOURCE

Displays the source selection bar.

- VOLUME +/VOLUME -Adjusts the sound level.
- 17. BRIGHT

Displays the BRIGHTNESS setting bar. See "Adjusting Brightness" on page 41 for details.

18. CONTRAST

Displays the CONTRAST setting bar. See "Adjusting Contrast" on page 41 for details

19. MUTE

Toggles projector audio between on and off.


20. LAMP MODE

Displays the Lamp Mode OSD menu.

Operating the LASER pointer

The Laser Pointer is a presentation aid for professionals. It emits a beam of red light when you press it.

The laser beam is visible. It is necessary to press and hold LASER for continuous output.





Do not look into the laser light window or shine the laser light beam on yourself or others. See the warning messages on the back of the remote control prior to using it.

The laser pointer is not a toy. Parents should be mindful of the dangers of laser energy and keep this remote control out of the reach of children.


Introduction 17

Remote control effective range

Infra-Red (IR) remote control sensor is located on the front and the rear of the projector. The remote control must be held at an angle within 30 degrees perpendicular to the projector's IR remote control sensor to function correctly. The distance between the remote control and the sensor should not exceed 8 meters (~ 26 feet).


Make sure that there are no obstacles between the remote control and the IR sensor on the projector that might obstruct the infra-red beam.





Replacing the remote control battery

- To open the battery cover, turn the remote control over to view its back, push on the finger grip on the cover and slide it up in the direction of the arrow as illustrated. The cover will slide off.
- Remove any existing batteries (if necessary) and install two AAA batteries observing
 the battery polarities as indicated in the base of the battery compartment. Positive
 (+) goes to positive and negative (-) goes to negative.
- 3. Refit the cover by aligning it with the base and sliding it back down into position. Stop when it clicks into place.





- · Avoid excessive heat and humidity.
- There may be battery damage if the battery is incorrectly replaced.
- Replace only with the same or equivalent type recommended by the battery manufacturer.
- Dispose of the used battery according to the battery manufacturer's instructions.
- Never throw a battery into a fire. There may be danger of an explosion.
- If the battery is dead or if you will not be using the remote control for a long time, remove the battery to
 prevent damage to the remote control from possible battery leakage.

Introduction 19


Positioning your projector

Choosing a location

Your projector is designed to be installed in one of four possible installation locations:

I. Front Table

Select this location with the projector placed on a table in front of the screen. This is the most common way to position the projector for quick setup and portability.




2. Rear Table

Select this location with the projector placed on a table behind the screen.

Note that a special rear projection screen is required.

*Set Rear Table in the SYSTEM SETUP: Basic > Projector Installation menu after you turn the projector on.




3. Front Ceiling

Select this location with the projector suspended upside-down from the ceiling in front of the screen.

Purchase the BenQ Projector Ceiling Mounting Kit from your dealer to mount your projector on the ceiling.

*Set Front Ceiling in the SYSTEM SETUP: Basic > Projector Installation menu after you turn the projector on.




4. Rear Ceiling

Select this location with the projector suspended upside-down from the ceiling behind the screen.

Note that a special rear projection screen and the BenQ Projector Ceiling Mounting Kit are required for this installation location.

*Set Rear Ceiling in the SYSTEM SETUP: Basic > Projector Installation menu after you turn the projector on.




Your room layout or personal preference will dictate which installation location you select. Take into consideration the size and position of your screen, the location of a suitable power outlet, as well as the location and distance between the projector and the rest of your equipment.

Obtaining a preferred projected image size

The distance from the projector lens to the screen, the zoom setting (if available), and the video format each factors in the projected image size.

Projection dimensions

Refer to "Dimensions" on page 88 for the center of lens dimensions of this projector before calculating the appropriate position.



SH915The screen aspect ratio is 16:9 and the projected picture is 16:9.

Screen size			Distance from screen [mm]			Offset [mm]	
Diag	gonal	Width	Height	Min Dis-	Average	Max Dis-	A [mm]
inch	mm	mm	mm	tance		tance	@ Wide mode
50	1270	1107	623	15 4 7	1930	2313	93
60	1524	1328	7 4 7	1857	2317	2776	112
70	1778	1550	872	2166	2703	3239	131
80	2032	1771	996	2476	3089	3701	149
90	2286	1992	1121	2784	3475	4164	168
100	2540	2214	1245	3095	3861	4627	187
110	2794	2435	1370	3404	4247	5090	205
120	3048	2657	1494	3714	4633	5552	224
130	3302	2878	1619	4023	5019	6015	243
140	3556	3099	1743	4333	5405	6478	262
150	3810	3321	1868	4642	5791	6940	280
160	4064	3542	1992	4952	6177	7403	299
170	4318	3763	2117	5261	6563	7866	318
180	4572	3985	2241	5571	6950	8328	336
190	4826	4206	2366	5880	7336	8791	355

Screen size			Distanc	Offset [mm]			
Diag	gonal	Width	Height	Min Dis-	Average	Max Dis-	A [mm]
inch	mm	mm	mm	tance		tance	@ Wide mode
200	5080	4428	2491	6190	7722	9254	374
250	6350	5535	3113	7737	9652	11567	467
300	7620	6641	3736	9285	11583	13881	560

SW916The screen aspect ratio is 16:10 and the projected picture is 16:10.

Screen size			Distanc	e from scre	en [mm]	Offset [mm]	
Diagonal		Width	Height	Min Dis-	Average	Max Dis-	A [mm]
inch	mm	mm	mm	tance		tance	@ Wide mode
50	1270	1077	673	1581	1972	2363	77
60	1524	1292	808	1897	2367	2836	93
70	1778	1508	942	2213	2761	3309	108
80	2032	1723	1077	2529	3155	3781	124
90	2286	1939	1212	2846	3550	4254	139
100	2540	2154	1346	3162	3944	4727	155
110	2794	2369	1481	3478	4339	5199	170
120	3048	2585	1615	3794	4733	5672	186
130	3302	2800	1750	4110	5128	6145	201
140	3556	3015	1885	4426	5522	6617	217
150	3810	3231	2019	4743	5916	7090	232
160	4064	3446	2154	5059	6311	7563	248
170	4318	3662	2289	5375	6705	8036	263
180	4572	3877	2423	5691	7100	8508	279
190	4826	4092	2558	6007	7494	8981	294
200	5080	4308	2692	6323	7889	9454	310
250	6350	5385	3365	7904	9861	11817	387
300	7620	6462	4039	9485	11833	14180	464


There is 5% tolerance among these numbers due to optical component variations. BenQ recommends that if you intend to permanently install the projector, you should physically test the projection size and distance using the actual projector before you permanently install it, so as to make allowance for this projector's optical characteristics. This will help you determine the exact mounting position so that it best suits your installation location.

Connection

When connecting a signal source to the projector, be sure to:

- 1. Turn all equipment off before making any connections.
- 2. Use the correct signal cables for each source.
- 3. Ensure the cables are firmly inserted.

In the connections shown below, some cables may not be included with the projector (see "Shipping contents" on page 9). They are commercially available from electronics stores.



- I. VGA cable
- 2. VGA to DVI-A cable
- 3. USB cable
- 4. HDMI cable
- 5. S-Video cable

- 6. Video cable
- 7. Audio cable
- 8. Audio L/R cable
- 9. USB flash driver/USB wireless dongle

Connection 23

Many notebooks do not turn on their external video ports when connected to a projector. Usually a key combo like FN + F3 or CRT/LCD key turns the external display on/off. Locate a function key labeled CRT/LCD or a function key with a monitor symbol on the notebook. Press FN and the labeled function key simultaneously. Refer to your notebook's documentation to find your notebook's key combination.

Connecting video source devices

You need only connect the projector to a video source device using just one of the connecting methods, however each provides a different level of video quality. The method you choose will most likely depend upon the availability of matching terminals on both the projector and the video source device as described below:

Terminal name	Terminal appearance	Picture quality
HDMI	HDMI-1 HDMI-2	Best
Component Video	COMPUTER-I COMPUTER-2	Better
S-Video	S-VIDEO	Good
Video	VIDEO (i)	Normal

Connecting audio

The projector has one built-in mono speaker which are designed to provide basic audio functionality accompanying data presentations for business purposes only. They are not designed for, nor intended for stereo audio reproduction use as might be expected in home theater or home cinema applications. Any stereo audio input (if provided), is mixed into a common mono audio output through the projector speaker.

The built-in speaker will be muted when the **AUDIO OUT** jack is connected.



- The projector is only capable of playing mixed mono audio, even if a stereo audio input is connected. See "Connecting audio" on page 24 for details.
- If the selected video image is not displayed after the projector is turned on and the correct video source
 has been selected, check that the video source device is turned on and operating correctly. Also check
 that the signal cables have been connected correctly.

Playing sound through the projector

You can make use of the projector (mixed mono) speaker in your presentations, and also connect separate amplified speakers to the AUDIO OUT socket of the projector.

If you have a separate sound system, you will most likely want to connect the audio output of your Video source device to that sound system, instead of to the mono audio projector.

Once connected, the audio can be controlled by the projector On-Screen Display (OSD) menus

The table below describes the connection methods for different devices, and where the sound is from.

Device	Computer/PC	Component/ S Video/Video	HDMI I/2
Audio input port	AUDIO IN (mini jack)	AUDIO (L/R)	HDMI
The projector can play the sound from	AUDIO IN (mini jack)	AUDIO (L/R)	HDMI
Audio output port	AUDIO OUT	AUDIO OUT	AUDIO OUT

The selected input signal determines which sound will be played by the projector speaker, and which sound will be output from the projector when AUDIO OUT is connected. If you select the COMPUTER/PC signal, the projector can play the sound received from AUDIO IN mini jack. If you select the COMPONENT/VIDEO signal, the projector can play the sound received from AUDIO (L/R).


Connection 25

The projector can play sound if the connected RJ45 or USB cable carries audio signal. There is no need to connect the audio cable when the USB Display or Network Display source is selected.

Operation

Starting up the projector

- Remove the lens cap.
- Plug the power cord into the projector and into a wall socket. Turn on the wall socket switch (where fitted). Check that the **POWER** indicator light on the projector lights orange after power has been applied.
- Please use the original accessories (e.g. power cable) only with the device to avoid possible dangers such as electric shock and fire.



The start up procedure takes about 30 seconds. In the later stage of start up, a startup logo is projected.

(If necessary) Rotate the focus ring to adjust the image clearness.

To turn off the ring tone, see "Turning off the Power on/off ring tone" on page 47 for details.

indicator light flashes green and stays green when the projector is on.

If the projector is still hot from previous activity, it will run the cooling fan for approximately 90 seconds before energizing the lamp.


- 4. To use the OSD menus, please set them to your familiar language first.
- If you are prompted for a password, press the arrow keys to enter a six digit password. See "Utilizing the password function" on page 34 for details.
- 6. Switch all of the connected equipment on.
- The projector will start to search for input signals. The current input signal being scanned displays in the upper left corner of the screen.


If the projector doesn't detect a valid signal, the message 'No Signal' will continue displaying until an input signal is found.

You can also press **SOURCE** on the projector or remote control to select your desired input signal. See "Switching input signal" on page 37 for details.

If the frequency/resolution of the input signal exceeds the projector's operating range, you will see the message 'Out of Range' displayed on a blank screen. Please change to an input signal which is compatible with the projector's resolution or set the input signal to a lower setting. See "Timing chart" on page 89 for details.

1 To maintain the lamp life, once you turn the projector on, wait at least 5 minutes before turning if off.





Hrvatski

PLEASE SELECT LANGUAGE


Adjusting the projected image

Adjusting the projection angle

The projector is equipped with I quick-release adjuster foot and I rear adjuster foot. These adjusters change the image height and projection angle. To adjust the projector:

- Press the quick-release button and lift the front of the projector. Once the image is positioned where you want it, release the quick-release button to lock the foot in position.
- 2. Screw the rear adjuster foot to fine tune the horizontal angle.

To retract the foot, hold up the projector while pressing the quick-release button, then slowly lower the projector. Screw the rear adjuster foot in a reverse direction.



If the projector is not placed on a flat surface or the screen and the projector are not perpendicular to each other, the projected image becomes trapezoidal. To correct this situation, see "Correcting keystone" on page 28 for details.



- Do not look into the lens while the lamp is on. The strong light from the lamp may cause damage to your
 eves.
- · Be careful when you press the adjuster button as it is close to the exhaust vent where hot air comes from.

Auto-adjusting the image

In some cases, you may need to optimize the picture quality. To do this, press **AUTO** on the projector or remote control. Within 3 seconds, the built-in Intelligent Auto Adjustment function will re-adjust the values of Frequency and Clock to provide the best picture quality.

The current source information will be displayed in the upper left corner of the screen for 3 seconds.




- The screen will be blank while AUTO is functioning.
- This function is only available when PC signal (analog RGB) is selected.


Operation 27

Fine-tuning the image size and clarity

 Adjust the projected image to the size that you need using the ZOOM ring.



2. Sharpen the image by rotating the FOCUS ring.



Correcting keystone

Keystoning refers to the situation where the projected image is noticeably wider at either the top or bottom. It occurs when the projector is not perpendicular to the screen.

To correct this, besides adjusting the height of the projector, you can use **Auto Keystone** or **Keystone** manually correct it following one of these steps.

Using the remote control

Press \(\bigsim / \) on the projector or remote control to display the Keystone correction page. Press \(\bigsim \) to correct keystoning at the top of the image. Press \(\bigsim \) to correct keystoning at the bottom of the image.



- Using the OSD menu
- 1. Press **MENU/EXIT** and then press **◄/▶** until the **Display** menu is highlighted.
- Press ▼ to highlight Keystone and press MODE/ENTER. The Keystone correction page displays.
- 3. Press \(\bigcap \) to correct keystoning at the top of the image or press \(\bigcup \) to correct keystoning at the bottom of the image.

The function is only available for SH915.

Correcting 2D Keystone

2D Keystone function enables a wider projector installation area compared to conventional projectors with limited positioning in front of the screen.

To correct this, you will need to manually correct it following one of these steps.

Using the projector or remote control






- · Using the OSD menu
- Press MENU/EXIT and then press
 puntil the Display menu is highlighted.
- Press ▼ to highlight 2D Keystone and press MODE/ENTER. The 2D Keystone page displays.
- Press ▼/ ▲/ | / to adjust the keystone values.
- Using the QUICK INSTALL key
- I. Press **OUICK INSTALL** on the remote control.





- Press ▼ to highlight 2D Keystone and press MODE/ENTER. The 2D Keystone page displays.
- Press ▼/ ▲/ ▶/ to adjust the keystone values



Due to for 3D content the 2D keystone will be change to ID V-keystone only



Operation 29

Correcting Corner Fit


Manually adjust four corners of the image by setting the horizontal and vertical values.

- Using the OSD menu
- Press MENU/EXIT and then press
 puntil the Display menu is highlighted.
- Press ▼ to highlight Corner Fit and press MODE/ENTER. The Corner Fit page displays.
- Press ▲, ▼, ◄, ► to select one of the four corners and press MODE/ENTER.






- Press ▲/▼ to adjust vertical values from 0 to 60.
- Press
 to adjust horizontal values from 0 to 60.



- Using the QUICK INSTALL key
- I. Press QUICK INSTALL on the remote control.



 Follow the steps 2~4 in the above section. Press MODE/ENTER to set to default setting.



The function is only available for SW916.

Correcting Surface Fit

Manually correct geographic distortion by Surface Fit calibration function.

- · Using the OSD menu
- Press MENU/EXIT and then press
 puntil the Display menu is highlighted.
- Press ▼ to highlight Surface Fit and press MODE/ENTER. The Surface Fit page displays.
- Press ▲/▼ to select a Horizontal Surface Fit and press MODE/ENTER.



4. Press **◄/▶** to select the direction and press **MODE/ENTER**.







Only one Surface Fit setting will be stored so if you want to change from the previous direction to the other, the notice message will pop-up to remind you to reset the previous Surface Fit setting.



- Press ◀/► to adjust the left or/and right side convex or concave. Default is 0 and value is -40~0~40.
 Single side adjustment is only for distortion.
- For both sides of the horizontal surface fit, use ▲/▼ to adjust the center of the curve because it is not always at the center. Default is 0 and value is -40~0~40.
- Press ▲/▼ to select Vertical Surface Fit and press MODE/ENTER.

Operation



31


8. Press **◄/▶** to select the direction and press **MODE/ENTER**.







- Press ▲/▼ to adjust the top or/and bottom side convex or concave. Default is 0 and value is -40~0~40. Single side adjustment is only for distortion.
- For both sides of the vertical surface fit, use ◀/► to adjust the center of the curve because it is not always at the center. Default is 0 and value is -40~0~40.



- Using the QUICK INSTALL key
- I. Press QUICK INSTALL on the remote control.



- Press ▼ to highlight Surface Fit and press MODE/ENTER. The Surface Fit page displays.
- 3. Follow the steps 2~9 in the above section.





Using the menus

The projector is equipped with On-Screen Display (OSD) menus for making various adjustments and settings.

Below is the overview of the OSD menu.



To use the OSD menus, please set them to your familiar language first.

 Press MODE/ENTER on the projector or 3. remote control to turn the OSD menu on.



Press ▼ to highlight Language and press ◀/▶ to select a preferred language.



Use ◀/► to highlight the System Setup: 4.
 Basic menu.



 Press MODE/ENTER twice* on the projector or remote control to leave and save the settings.

> *The first press leads you back to the main menu and the second press closes the OSD menu.

Operation 33

Securing the projector

Using a security cable lock

The projector has to be installed in a safe place to prevent theft. Otherwise, purchase a lock, such as a Kensington lock, to secure the projector. You can locate a Kensington lock slot on the left side of the projector. See "Kensington anti-theft lock slot" on page 10 for details.

A Kensington security cable lock is usually a combination of key(s) and a lock. Refer to the lock's documentation for finding out how to use it.

Utilizing the password function

For security purposes and to help prevent unauthorized use, the projector includes an option for setting up password security. The password can be set through the On-Screen Display (OSD) menu.

WARNING: You will be inconvenienced if you activate the power-on lock functionality and subsequently forget the password. Print out this manual (if necessary) and write the password you used in this manual, and keep the manual in a safe place for later recall.

Setting a password

- Once a password has been set, the projector cannot be used unless the correct password is entered every time the projector is started.
 - Open the OSD menu and go to the System Setup: Advanced > Security Settings menu. Press MODE/ENTER. The Security Settings page displays.
 - 2. Highlight Change Security Settings and press MODE/ENTER.
 - As pictured to the right, the four arrow keys (▲, ▼, ◄, ►) respectively represent 4 digits (1, 2, 3, 4). According to the password you desire to set, press the arrow keys to enter six digits for the password.
 - Confirm the new password by re-entering the new password.
 - Once the password is set, the OSD menu returns to the **Security Settings** page.



- To activate the Power on Lock function, press ▲/▼ to highlight Power on Lock and press ◄/► to select On.
- 6. To activate the Web Control Lock function, press ▲/▼ to highlight Web Control Lock and press ◄/▶ to select On.
 When the Web Control Lock is activated, you have to enter the correct password to change projector settings via the Projector Network Display System

The digits being input will display as asterisks on-screen. Write your selected password down here in this
manual in advance or right after the password is entered so that it is available to you should you ever forget it.

Password:	
Koop this manual	in a safe place

•

7. To leave the OSD menu, press **MENU/EXIT.**

If you forget the password

If the password function is activated, you will be asked to enter the six-digit password every time you turn on the projector. If you enter the wrong password, the password error message as pictured to the right displays lasting for three seconds, and the message 'INPUT PASSWORD' follows. You can retry by entering another six-digit password, or if you did not



record the password in this manual, and you absolutely do not remember it, you can use the password recall procedure. See "Entering the password recall procedure" on page 35 for details.

If you enter an incorrect password 5 times in succession, the projector will automatically shut down in a short time.

Entering the password recall procedure

- Press and hold **AUTO** on the projector or remote control for 3 seconds. The projector will display a coded number on the screen.
- Write down the number and turn off your projector.
- Seek help from the local BenQ service center to decode the number. You may be required to provide proof of purchase documentation to verify that you are an authorized user of the projector.



Changing the password

- Open the OSD menu and go to the System Setup: Advanced > Security Settings > Change password menu.
- 2. Press MODE/ENTER. The message 'INPUT CURRENT PASSWORD' displays.
- 3. Enter the old password.
 - If the password is correct, another message 'INPUT NEW PASSWORD' displays.
 - If the password is incorrect, the password error message displays lasting for three seconds, and the message 'INPUT CURRENT PASSWORD' displays for your retry. You can press MENU/EXIT to cancel the change or try another password.
- 4. Enter a new password.

	The digits being input will display as asterisks on-screen. Write your selected password down here in this
_	manual in advance or right after the password is entered so that it is available to you should you ever forget it.

Password: ______

Keep this manual in a safe place.

5. Confirm the new password by re-entering the new password.

Operation 35

- You have successfully assigned a new password to the projector. Remember to enter the new password next time the projector is started.
- 7. To leave the OSD menu, press **MENU/EXIT**.



Disabling the password function

To disable password protection, go back to the **System Setup: Advanced > Security Settings > Change Security Settings** menu after opening the OSD menu system. Press **MODE/ENTER**. The message "**INPUT PASSWORD**" appears. Enter the current password.

- i. If the password is correct, the OSD menu returns to the Security Settings.
 Press ▼ highlight Power On Lock and press ▼ /▶ to select Off. You will not have to enter the password next time you turn on the projector.
 Press ▼ to highlight Web Control Lock and press ▼ /▶ to select Off. The Web Control Lock function is released and the projector settings can be change via the Projector Network System.
- ii. If the password is incorrect, the password error message displays lasting for three seconds, and the message 'INPUT PASSWORD' displays for your retry. You can press MENU/EXIT to cancel the change or try another password.

Though the password function is disabled, you need to keep the old password in hand should you ever need to re-activate the password function by entering the old password.

Switching input signal

The projector can be connected to multiple devices at the same time. However, it can only display one full screen at a time.

Be sure the **Quick Auto Search** function in the **Source** menu is **On** (which is the default of this projector) if you want the projector to automatically search for the signals.

You can also manually cycle through the available input signals.

- Press SOURCE on the projector or press input source directly from the remote control. A source selection bar displays.
- Press ▲/▼ until your desired signal is selected and press MODE/ENTER.
 Once detected, the selected source information will display on the screen for seconds. If there is multiple equipment connected to the projector, repeat steps 1-2 to search for another signal.
- The brightness level of the projected image will change accordingly when you switch between different input signals. Data (graphic) "PC" presentations using mostly static images are generally brighter than "Video" using mostly moving images (movies).
 - For best display picture results, you should select and use an input signal which outputs at this resolution.
 Any other resolutions will be scaled by the projector depending upon the 'aspect ratio' setting, which may cause some image distortion or loss of picture clarity. See "Selecting the aspect ratio" on page 38 for details

Changing Color Space

In the unlikely event that you connect the projector to a DVD player via the projector's **HDMI** input and the projected picture displays wrong colors, please change the color space.

To do this:

- 1. Press **MENU/EXIT** and then press **◄/▶** until the **SOURCE** menu is highlighted.
- Press ▼ to highlight Color Space Conversion and press ◄/► to select the setting.

This function is only available when the HDMI input socket is in use.

Magnifying and searching for details

If you need to find the details on the projected picture, magnify the picture. Use the direction arrow keys for navigating the picture.

- Using the remote control
- Press Digital Zoom+/- to display the Zoom bar. Press Digital Zoom+ to magnify the center of the picture. Press the key repeatedly until the picture size is suitable for your need.
- Use the directional arrows (▲, ▼, ◄, ►) on the projector or remote control to navigate the picture.
- To restore the picture to its original size, press AUTO. You can also press Digital
 Zoom-. When the key is pressed again, the picture is further reduced until it is
 restored to the original size.
- · Using the OSD menu
- I. Press **MENU/EXIT** and then press **◄/▶** until the **Display** menu is highlighted.
- Press ▼ to highlight Digital Zoom and press MODE/ENTER. The Zoom bar displays.
- 3. Press ▼ on the projector repeatedly to magnify the picture to a desired size.
- To navigate the picture, press MODE/ENTER to switch to the paning mode and press the directional arrows (▲, ▼, ◄, ►) to navigate the picture.
- 5. To reduce size of the picture, press MODE/ENTER to switch back to the zoom in/ out functionality, and press AUTO to restore the picture to its original size. You can also press ▼ repeatedly until it is restored to the original size.
- The picture can only be navigated after the picture is magnified. You can further magnify the picture while searching for details.

Selecting the aspect ratio

The 'aspect ratio' is the ratio of the image width to the image height. Most analog TV and computers are in 4:3 ratio, and digital TV and DVDs are usually in 16:9 ratio.

With the advent of digital signal processing, digital display devices like this projector can dynamically stretch and scale the image output to a different aspect than that of the image input signal.


To change the projected image ratio (no matter what aspect the source is):

- Using the remote control
- Press Aspect to show the current setting.
- Press Aspect repeatedly to select an aspect ratio to suit the format of the video signal and your display requirements.
- Using the OSD menu
- I. Press **MENU/EXIT** and then press **◄/▶** until the **Display** menu is highlighted.
- Press ▼ to highlight Aspect Ratio.
- Press ◄/► to select an aspect ratio to suit the format of the video signal and your display requirements.


About the aspect ratio

In the pictures below, the black portions are inactive areas and the white portions are active areas. OSD menus can be displayed on those unused black areas.


 Auto: Scales an image proportionally to fit the projector's native resolution in its horizontal width. This is suitable for the incoming image which is neither in 4:3 nor 16:9 and you want to make most use of the screen without altering the image's aspect ratio.




2. Real: The image is projected as its original resolution, and resized to fit within the display area. For input signals with lower resolutions, the projected image will display smaller than if resized to full screen. You could adjust the zoom setting or move the projector away from the screen to increase the image size if necessary. You may also need to refocus the projector after making these adjustments.




 4:3: Scales an image so that it is displayed in the center of the screen with a 4:3 aspect ratio. This is most suitable for 4:3 images like computer monitors, standard definition TV and 4:3 images aspect DVD movies, as it displays them without aspect alteration.



4. 16:9: Scales an image so that it is displayed in the center of the screen with a 16:9 aspect ratio. This is most suitable for images which are already in a 16:9 aspect, like high definition TV, as it displays them without aspect alteration.



 16:10: Scales an image so that it is displayed in the center of the screen with a 16:10 aspect ratio. This is most suitable for images which are already in a 16:10 aspect, as it displays them without aspect alteration.



Optimizing the image

Using Wall Color

In the situation where you are projecting onto a colored surface such as a painted wall which may not be white, the **Wall Color** feature can help correct the projected picture's color to prevent possible color difference between the source and projected pictures.

To use this function, go to the **Display** > **Wall Color** menu and press **◄**/**▶** to select a color which is the closest to the color of the projection surface. There are several precalibrated colors to choose from: **Light Yellow**, **Pink**, **Light Green**, **Blue**, and **Blackboard**.

Selecting a picture mode

The projector is preset with several predefined picture modes so that you can choose one to suit your operating environment and input signal picture type.

To select an operation mode that suits your need, you can follow one of the following steps.

- Press MODE/ENTER on the projector repeatedly until your desired mode is selected.
- Go to the Picture > Picture Mode menu and press ◄/▶ to select a desired mode.
- Dynamic mode: Maximizes the brightness of the projected image. This mode is suitable for environments where extra-high brightness is required, such as using the projector in well lit rooms.
- 2. **Presentation mode**: Is designed for presentation. The brightness is emphasized in this mode to match PC and notebook coloring..
- sRGB mode: Maximizes the purity of RGB colors to provide true-to-life images regardless of brightness setting. It is most suitable for viewing photos taken with an sRGB compatible and properly calibrated camera, and for viewing PC graphic and drawing applications such as AutoCAD.
- Cinema mode: Is appropriate for playing colorful movies, video clips from digital cameras or DVs through the PC input for best viewing in a blackened (dimly lit) environment.
- 5. **3D mode**: Is appropriate for playing 3D images and 3D video clips.
- User I/User 2 mode: Recalls the settings customized based on the current available picture modes. See "Setting the User I/User 2 mode" on page 40 for details.

Setting the User I/User 2 mode

There are two user-definable modes if the current available picture modes are not suitable for your need. You can use one of the picture modes (except the **User 1/User 2**) as a starting point and customize the settings.

- 1. Press **MENU/EXIT** to open the On-Screen Display (OSD) menu.
- 2. Go to the **Picture > Picture Mode** menu.
- Press ◀/▶ to select User I to User 2.
- Press ▼ to highlight Reference Mode.
- This function is only available when **User 1** or **User 2** mode is selected up in the **Picture Mode** sub-menu item.
 - 5. Press **◄/▶** to select a picture mode that is closest to your need.

Press ▼ to select a sub-menu item to be changed and adjust the value with ◄/▶.
 See "Fine-tuning the image quality in user modes" below for details.

Fine-tuning the image quality in user modes

According to the detected signal type, and selected picture mode, some of the functions listed below may not be available. Base on your need, you can make adjustments to these functions by highlighting them and press ◀/▶ on the projector or remote control.

Adjusting Brightness

The higher the value, the brighter the image. And lower the setting, darker the image. Adjust this control so the black areas of the image appear just as black and that detail in the dark areas is visible.



Adjusting Contrast

The higher the value, the greater the contrast. Use this to set the peak white level after you have previously adjusted the **Brightness** setting to suit your selected input and viewing environment.



Adjusting Color

Lower setting produces less saturated colors. If the setting is too high, colors on the image will be overpowering, which makes the image unrealistic.

Adjusting Tint

The higher the value, the more reddish the picture becomes. The lower the value, the more greenish the picture becomes.

Adjusting Sharpness

The higher the value, the sharper the picture becomes. The lower the value, the softer the picture becomes.

Adjusting Brilliant Color

This feature utilizes a new color-processing algorithm and system level enhancements to enable higher brightness while providing truer, more vibrant colors in picture. It enables a greater than 50% brightness increase in mid-tone images, which are common in video and natural scenes, so the projector reproduces images in realistic and true colors. If you prefer images with that quality, select **On**. If you don't need it, select **Off**.

When **Off** is selected, the **Color Temperature** function is not available.

Selecting a Color Temperature

The options available for color temperature* settings vary according to the signal type selected.

- 1. **Cooler:** makes the image appear bluish white.
- 2. Normal: Maintains normal colorings for white.
- 3. Warm: Makes images appear reddish white.

*About color temperatures:

There are many different shades that are considered to be "white" for various purposes. One of the common methods of representing white color is known as the "color temperature". A white color with a low color temperature appears to be reddish white. A white color with a high color temperature appears to have more blue in it.

Setting a preferred color temperature

To set a preferred color temperature:

- Highlight Color Temperature and select Warm, Normal or Cool by pressing
 ◄/▶ on the projector or remote control.
- Press ▼ to highlight Color Temperature Fine Tuning and press MODE/ ENTER. The Color Temperature Fine Tuning page appears.
- Press ▲/▼ to highlight the item you want to change and adjust the values by pressing ◄/►.
 - R Gain/G Gain/B Gain: Adjusts the contrast levels of Red, Green, and Blue.
 - R Offset/G Offset/B Offset: Adjusts the brightness levels of Red, Green, and Blue.
- 4. Press **MENU/EXIT** to exit and save the settings

3D Color Management

In most installation situations, color management will not be necessary, such as in classroom, meeting room, or lounge room situations where lights remain on, or where building external windows allow daylight into the room.

Only in permanent installations with controlled lighting levels such as boardrooms, lecture theaters, or home theaters, should color management be considered. Color management provides fine color control adjustment to allow for more accurate color reproduction, should you require it.

Proper color management can only be achieved under controlled and reproducible viewing conditions. You will need to use a colorimeter (color light meter), and provide a set of suitable source images to measure color reproduction. These tools are not provided with the projector, however, your projector supplier should be able to provide you with suitable guidance, or even an experienced professional installer.

The Color Management provides six sets (RGBCMY) of colors to be adjusted. When you select each color, you can independently adjust its range and saturation according to your preference.

If you have purchased a test disc which contains various color test patterns and can be used to test the color presentation on monitors, TVs, projectors, etc. You can project any image from the disc on the screen and enter the **3D Color Management** menu to make adjustments.

To adjust the settings:


- 1. Go to the **Picture** menu and highlight **3D Color Management**.
- 2. Press MODE/ENTER and the 3D Color Management page displays.
- Highlight Primary color and press ◄/► to select a color from among Red, Green, Blue, Cyan, Magenta and Yellow.
- Press ▼ to highlight Hue and press ◄/► to select its range. Increase in the range will include colors consisted of more proportions of its two adjacent colors.

Please refer to the illustration to the right for how the colors relate to each other.

For example, if you select Red and set its range at 0, only pure red in the projected picture will be selected. Increasing its range will include red close to yellow and red close to magenta.

5. Press ▼ to highlight Saturation and adjust its values to your preference by pressing ◄/
 ▶. Every adjustment made will reflect to the image immediately.

For example, if you select Red and set its value at 0, only the saturation of pure red will be affected.



- Saturation is the amount of that color in a video picture. Lower settings produce less saturated colors; a setting of "0" removes that color from the image entirely. If the saturation is too high, that color will be overpowering and unrealistic.
 - Press ▼ to highlight Gain and adjust its values to your preference by pressing ◄/▶.
 The contrast level of the primary color you select will be affected. Every adjustment made will reflect to the image immediately.
 - 7. Repeat steps 3 to 6 for other color adjustments.
 - 8. Make sure you have made all of the desired adjustments.
 - 9. Press **MENU/EXIT** to exit and save the settings.

Resetting current or all picture modes

- 1. Go to the **Picture** menu and highlight **Reset Picture Settings**.
- Press MODE/ENTER and press ▲/▼ to select Current or All.
 - **Current**: returns current picture mode to the factory preset settings.
 - All: returns all settings, except User I/User 2 in the Picture menu to the factory preset settings.

Setting the presentation timer

Presentation timer can indicate the presentation time on the screen to help you achieve better time management when giving presentations. Follow these steps to utilize this function:

- Go to the System Setup: Basic > Presentation Timer menu and press MODE/ ENTER to display the Presentation Timer page.
- Highlight Timer Period and decide the time period by pressing
 The length of time can be set from 1 to 5 minutes in 1-minute increments and 5 to 240 minutes in 5-minute increments.

If the timer is already on, the timer will restart whenever the Timer Period is reset.

 Press ▼ to highlight Timer Display and choose if you want the timer to show up on the screen by pressing ◄/►.

Selection	Description	
Always	Displays the timer on screen throughout the presentation time.	
3 min/2 min/1 min	Displays the timer on screen in the last 3/2/1 minute(s).	
Never	Hides the timer throughout the presentation time.	

- 4. Press ▼ to highlight **Timer Position** and set the timer position by pressing ◀/▶.
- Press ▼ to highlight Timer Counting Direction and select your desired counting direction by pressing ◄/►.

Selection	Description	
Count Up	Increases from 0 to the preset time.	
Count Down	n Decreases from the preset time to 0.	

- 6. Press ▼ to highlight Sound Reminder and decide if you want to activate sound reminder by pressing ◀/▶. If you select On, a double beep sound will be heard at the last 30 seconds of counting down/up, and a triple beep sound will be produced when the timer is up.
- To activate the presentation timer, press ▼ and press ◄/► to highlight On and press MODE/ENTER.
- A confirmation message appears. Highlight Yes and press MODE/ENTER on the projector or remote control to confirm. You will see the message "Timer is On" appearing on the screen. The timer starts counting when the timer is on.

To cancel the timer, perform the following steps:

- Go to the System Setup: Basic > Presentation Timer menu and highlight Off. Press MODE/ENTER. A confirmation message appears.
- Highlight Yes and press MODE/ENTER to confirm. You will see the message "Timer is Off" appearing on the screen.

Remote paging operations

Connect the projector to your PC or notebook with a USB cable prior to using the paging function. See "Connection" on page 23 for details.

You can operate your display software program (on a connected PC) which responds to page up/down commands (like Microsoft PowerPoint) by pressing **PAGE +/PAGE -** on the remote control.

If remote paging function doesn't work, check if the USB connection is correctly made and the mouse driver on your computer is updated to the latest version.

- The remote paging function cannot work with Microsoft[®] Windows[®] 98 operating system. Windows[®] XP or higher operating systems are recommended.
 - The function is only available for SH915.

Freezing the image

Press **FREEZE** on the remote control to freeze the image. The word '**FREEZE**' will appear on the screen. To release the function, press any key on the projector or remote control.

If your remote control has the following keys, please note that they cannot be pressed to release the function: **LASER**, #2, #5, **PAGE** +/**PAGE** -.

Even if an image is frozen on the screen, the pictures are running on the video or other device. If the connected devices have active audio output, you will still hear the audio even though the image is frozen on screen.

Hiding the image

In order to draw the audience's full attention to the presenter, you can use **ECO BLANK** on the projector or **ECO BLANK** on the remote control to hide the screen image. When the function is activated with an audio input connected, the audio can still heard.

You can set the blank time in the **System Setup: Basic > Operating Settings > Blank Timer** menu to let the projector return the image automatically after a period of time when there is no action taken on the blank screen. The length of time can be set from 5 to 30 minutes in 5-minute increments.

If the preset time spans are not suitable for your presentation, select **Disable**.

No matter **Blank Timer** is activated or disabled, you can press most of the keys on the projector or remote control to restore the picture.



Do not block the projection lens from projecting as this could cause the blocking object to become heated and deformed or even cause a fire.

Locking control keys

With the control keys on the projector locked, you can prevent your projector settings from being changed accidentally (by children, for example). When the **Panel Key Lock** is on, no control keys on the projector will operate except $|\overline{\mathbb{O}}|$ **POWER**.

- Go to the System Setup: Basic > Panel Key Lock menu, and select On by pressing ◄/▶ on the projector or remote control. A confirmation message appears.
- 2. Highlight **Yes** and press **MODE/ENTER** to confirm.

To release panel key lock, use the remote control to enter the **System Setup: Basic > Panel Key Lock** menu and press **◄/▶** to select **Off**.



• If you press O POWER to turn off the projector without disabling panel key lock, the projector will still be in locked status the next time it is turned on.

Operating in a high altitude environment

We recommend you use the **High Altitude Mode** when your environment is between 1500 m -3000 m above sea level, and temperature is between 0°C-30°C.



Do not use the **High Altitude Mode** if your altitude is between 0 m and 1500 m and temperature is between 0° C and 35°C. The projector will be over cooled, if you turn the mode on under such a condition.

To activate the **High Altitude Mode**:

- Press MENU/EXIT and then press <a>
 ✓ I until the System Setup: Advanced menu is highlighted.
- 2. Press ▼ to highlight **High Altitude Mode** and press ◀/▶ to select **On**. A confirmation message displays.
- Highlight Yes and press MODE/ENTER.

Operation under "High Altitude Mode" may cause a higher decibel operating noise level because of increased fan speed necessary to improve overall system cooling and performance.

If you use this projector under other extreme conditions excluding the above, it may display auto shut-down symptoms, which is designed to protect your projector from overheating. In cases like this, you should switch to High Altitude mode to solve these symptoms. However, this is not to state that this projector can operate under any and all harsh or extreme conditions.

Adjusting the sound

The sound adjustments made as below will have an effect on the projector speakers. Be sure you have made a correct connection to the projector audio input. See "Connection" on page 23 for how the audio input is connected.

INPUT SOURCE	AUDIO IN	AUDIO OUT
Computer	mini jack	mini jack
HDMI I/2	HDMI	mini jack
VIDEO	RCA	mini jack
S-VIDEO	RCA	mini jack

Muting the sound

To temporarily turn off the sound,

Using the remote control

Press MUTE to temporarily turn off the sound. While the sound is off, the screen will display in the upper right corner of the screen.

To restore the sound, press **MUTE** again.

- Using the OSD menu
- Press MENU/EXIT and then press <a>
 ✓ I until the System Setup: Advanced menu is highlighted.
- 2. Press ▼ to highlight Audio Settings and press MODE/ENTER. The Audio Settings page displays.
- 3. Highlight **Mute** and press **◄/▶** to select **On**.
- To restore the sound, repeat steps 1-3 and press
 ✓/► to select Off.

Adjusting the sound level

To adjust the sound level,

Using the remote control

Press or b) to select a desired sound level.

- · Using the OSD menu
- I. Repeat steps I-2 above.
- Press ▼ to highlight Volume and press ◄/▶ to select a desired sound level.

Turning off the Power on/off ring tone


- Repeat steps 1-2 above.
- Press ▼ to highlight Power on/off ring tone and press ◄/► to select Off.

The only way to change Power on/off ring tone is setting On or Off here. Setting the sound mute or changing the sound level will not affect the Power on/off ring tone.

Using the test pattern

The projector is capable of displaying the grid test pattern. It can be used to assist you with the adjustment of image size and focus, ensuring that the projected image is free from distortion.

To display the test pattern, open the OSD menu and go to the **System Setup: Advanced > Test Pattern** and press **◄/▶** to select **On**.



Using the teaching templates

The projector provides several preset patterns for various teaching purposes. To activate the pattern:

- Open the OSD menu and go to the Display > Teaching Template and press ▲/▼
 to select Blackboard or Whiteboard.
- 2. Press **◄/▶** to choose the pattern you need.
- 3. Press MODE/ENTER to activate the pattern.

Teaching Template	Whiteboard	Blackboard
Letter Formation		
Worksheet		
Coordinate Chart		

Using the quick install

The projector provides a hot key to set **Projector Installation**, **Test Pattern**, and **Keystone** quickly.


Press Quick Install on the remote control and press ▲/▼ to select:

- Projector Installation: See "Positioning your projector" on page 20.
- Test Pattern: See "Using the test pattern" on page 47.
- Keystone: See "Correcting keystone" on page 28.

Controlling the projector through a LAN environment

Network Settings allow you to manage the projector from a computer using a web browser when the computer and the projector are properly connected to the same local area network.

Configuring the Wired LAN Settings



If you are in a DHCP environment:


- Take a RJ45 cable and connect one end to the LAN input jack of the projector and the other end to the RJ45 port.
- Press MENU/EXIT and then press / until the System Setup: Advanced menu is selected.
- Press ▼ to select Network Settings and press MODE/ENTER. The Network Settings page displays.
- Press ▼ to select Wired LAN and press MODE/ENTER.
- Press ▼ to select DHCP and press ◄/▶ to select On.
- Press ▼ to select Apply and press MODE/ENTER.
- Re-enter the Wired LAN page. The IP Address, Subnet Mask, Default Gateway, and DNS Server settings will be displayed. Note down the IP address.

If the IP Address still does not display, contact your ITS administrator.

If you are in a non-DHCP environment:

- I. Repeat steps 1-4 above.
- 2. Press ▼ to select DHCP and press ◄/▶ to select Off.
- Contact your ITS administrator for information on the IP Address, Subnet Mask, Default Gateway, and DNS Server settings.
- 4. Press ▼ to select the item you want to modify and enter the value.
- Press ▼ to select Apply and press MODE/ENTER.

Configuring the Wireless LAN Settings



- Connect the BenQ wireless dongle (optional) to the USB TYPE-A input jack of the projector.
- Select Wireless LAN in System Setup: Advanced > Network Settings menu and press MODE/ENTER.
- For AP mode connection, you need to note SSID information, then search the
 projector with the same SSID in Q Presenter to start projection. For Infrastructure
 mode connection, you need to select the projector's SSID which you want to
 connect. See "Displaying image through Q Presenter" on page 58 for details.
- 4. Use your computer's wireless connection utility to connect the network.

[7] If WEP Key is set in the projector, the user must enter the password of WEP Key to connect the network.

Controlling the projector remotely through a web browser

Once you have configured the LAN settings, you can find the IP address for the projector in the bottom of the network screen. You can use any computer that is on the same local area network to control the projector.

 Enter the address of the projector in the address bar of your browser and press Enter. For example: http://172.28.120.1





- 2. The BenQ remote network operation page opens.
- The web page control supports IE version 7.0 or higher.
 - The illustrations in web page control, Q Presenter and USB Reader sections are for the purpose of explanation and may differ from the actual design of your projector.



- 3. Click Download to save Q Presenter software on your computer.
- You can also link to the web page control from **Q Presenter > Settings > Advanced Setting > Control projector** via web page on page 61.
 - 4. Execute the program installation.
 - Open Q Presenter, search and connect a network display. See "Displaying image through Q Presenter" on page 58 for details.

The Virtual Keypad page allows you to operate the projector as if you were using the remote control or control panel on the projector.



 These buttons function the same as the ones on the remote control. See "Remote Control" on page 14 for details.

The Display Setting page allows you to operate the projector as if you were using the OSD menus. These functions are some useful menu settings.



The Picture Setting page allows you to manage the projector as if you were using the **Picture** menu.



The Information page displays the information and status of this projector.



The Conference Control page allows you to control computer's display status of all the computers linked to this projector.



The Crestron page is only available when you are on a Wired LAN network. It also allows you to control the projector remotely. The Crestron supports RoomView version 6.2.2.9.



- These buttons function the same as the ones on the OSD menus or remote control. See "2. Picture menu" on page 73 and "Remote Control" on page 14 for details.
- The Menu button can also be used to go back to previous OSD menu, exit and save menu settings.
 - ii. To switch input source, click on your desired signal.
 - iii. You can select a preferred OSD language.

The tools page allows you to manage the projector, configure the LAN control settings and secure access of remote network operation on this projector.



- You can name the projector, keep track of its location and the person in charge of it.
- ii. You can adjust the Wired LAN settings.
- iii. Once set, access to the remote network operation on this projector has been password-protected.
- iv. Once set, access to the tools page has been password-protected.
- After making the adjusents, press the Send button and the data will be saved in the projector.
 - v. Press **exit** to go back to the Crestron remote network operation page. The info page displays the information and status of this projector.



i. Press exit to go back to the Crestron remote network operation page. The Admin page allows you to enter Basic, Wired LAN, Wireless LAN and Mail pages once the password is entered. The default password is "0000". If you want to change the password, please enter Basic page.



The Basic page allows you to change the password and select connected persons. The number of connected persons may affect the network display performance.



The Wired LAN page allows you to adjust the Wired LAN settings.



The Wireless LAN page allows you to adjust the Wirless LAN settings.



Max. length for SSID string is 16 bytes. Please use a different SSID when more than two projectors are connecting through wireless LAN.

The Mail page allows you to send alert e-mail to your ITS administrator.



You can first try the Mail Test function to check if the Alert Mail works.

Using the Web Control Lock

This function is designed to prevent unauthorized people from maliciously changing the projector settings through the Projector Network Display System.

To enable the function:

- After your computer is connected to the projector, enter the address of the projector in the address bar of your browser and press Enter.
- 2. Go to the Admin page of the Projector Network Display System.
- 3. Enter the current password.
- 4. Click ON in the Web Control Lock row.



The next time someone connects to this projector, the Projector Network Display System page provides limited functions.

To disable the function:

- 1. Go to the Admin page of the Projector Network Display System.
- 2. Enter the current password.
- Click OFF in the Web Control Lock row.

You can also use the OSD menu to toggle this function:

I. Go to the System Setup: Advanced > Security Settings > Change Security Settings menu after opening the OSD menu system. Press MODE/ENTER. The message "INPUT PASSWORD" appears. Enter the current password. If the password is correct, the OSD menu returns to the Security Settings page. Press ▼ to select Web Control Lock and press ◄/► to select On or Off.

Displaying image through Q Presenter

The Q Presenter is an application running on the host PC. It connects to an available network display and transfers the desktop contents to the network display via local network connection.

- Be sure to turn off other virtual network control programs before using Q Presenter.
 - Connect the projector with the RJ45 cable, and make sure your laptop or computer also link to the LAN. See "Configuring the Wired LAN Settings" on page 49 and "Configuring the Wireless LAN Settings" on page 50 for details.
 - Find the IP address and enter the address of the projector in the address bar of your browser. See "Controlling the projector remotely through a web browser" on page 50 for details.
 - 3. Download the Q Presenter, unzip it and complete program installation.
 - 4. Once installed, double click the Q Presenter icon. The Q Presenter page appears.

5. Click the Search icon.



The Search page allows you to search and connect a network display.




- i. You can key in the IP address (see "Controlling the projector remotely through a web browser" on page 50 for details.) or just click "Search".
- Projectors linked in the LAN will be found. Then select the projector you want to link.
- iii. Click "Connect". Then you should be able to see the image on projector.
- iv. You can click to disconnect all connected projectors.

The Special Feature page allows you to have some advanced functions to manage the display image on your projector.



i. Full Screen: whole image display on the projector. Selectable: a square will popup then you can move and drag the area you want to show the audience.



- You can select to Play/Pause displaying desktop contents to connected network isplay.
- iii. 4-1 Display (up to 4 computers can shoot to 1 projector at the same time). Click the location you want to display. 4locations can be chosen (1-4) or 2 places (L and R) if it's 2 computers. Once you click the place you want to display, the image appers on th eprojector. You can change th elocation anytime you want, even back to full screen or blank out.

The Basic and Advanced Settings pages allow you to configure the Q Presenter.



- i. You can select whether to activate Remote Desktop function. If the Remote Desktop function is activated, you can change the Name and Password. If it isn't activated, the Name and Password will be gray out.
- ii. You can set the name and password of the connected computer. The Name must be eight capital letters from A-Z & 0-9. The Password must be 6 digits from 1 to 4.

- iii. When you install the Q Presenter, the program will automatically identify the language of your computer's operating system and install the same language as your operating system. If your language isn't included, the system will keep English as the default setting.
- iv. You can select whether to allow notification message popup.
- v. Once you set to activate 1:N display, IPC/NB can display up to 8 projectors at the same time.
- vi. Once set, press Apply to save the changes.



- vii. You can select Video or Graphic display mode. Graphic Mode: worse image quality but faster tramsmission speed. Video Mode: better image quality but slower transmission speed. However, the actual transmission performance was determined by the status of network usage at that time.
- viii. You can select whether to automatically open the Q Presenter application when the computer is powered on.
- ix. Once set, press Apply to save the changes.
- x. You can link to the BenQ remote network operation page on page 50.

Using the Projection Login Code

This function is designed to ensure network display through the correct projector. To toggle this function:

- Go to the System Setup: Advanced > Network Settings menu after opening the OSD menu system. Press MODE/ENTER.
- 2. Press ▼ to select Projection Login Code and press ◄/▶ to select On or Off.

When this function is on, the projector generates a random 4-digit code in the upper right corner when you switch the source to Network Display. You need to key in this 4-digit code in the Q Presenter when connecting to the projector.



Using the broadcassting function

When it comes to I:N LAN Dispaly, there are two ways to do this function:

- I. By TCP/IP (support up to 8 porjectors, original design)
- 2. By Multicast(support up to 255 projectors, this new design)

You can select channel 1, 2, 3, 4, 5,6...25 with showing the corrspondent IP(gray out).

There are 1~25 channels (25IPs) for you to select freely:

239.192.19.21~239.192.19.45

If the channel is fixed at emergency channel, when projector detects image coming in from this channel, it will project this image automatically. There is no need to switch sources manually.

To acticate this function:

The function requires special version of the QPresenter. Please download it from your User Manuel CD.

- Go to the System Setup: Advanced > Network Settings menu after opening the OSD menu system. Press MODE/ENTER.
- 2. Press ▼ to select **Broadcasting** and press ◀/▶ to select **On**.
- 3. Open the Advanced Settings page in the Qpresenter.
- 4. Click Yes in the Activating Broadcasting row and click Apply.

Or

- 1. Open the Projector Network Display System and go to the Basic page.
- 2. Click **On** in the **Broadcasting** row and select a channel using the drop-down list.
- 3. Open the Advanced Settings page in the Qpresenter.
- 4. Click **Yes** in the Activating Broadcasting row and click **Apply**.
- This function is only available when the Network Display source is selected.
 - The minimum system requirement for your computer is Intel Core 2 Dou 2.4GHz CPU, 2G DDR.

Remote Desktop Control through Q Presenter

The Q Presenter can proceed the Remote Desktop Control (RDC) the host PC from projector site.

I. Setup the RDC login account (User name and Password) in Q Presenter.



- Name: must be 8 English capital letters A~Z and number 0 ~9.
- Password: must be 6 digits and limit the range from 1~4.
- If there are lot of audience is watching the display while the user is entering the
 password, the number will be transferred to up, left, down, right in order from I
 to 4 of remote control's or projector's keypads.
- If multiple same Q Presenter names are found, an error like "duplicate" is displayed in projector OSD.
- Activate Remote Desktop Control Function in Q Presenter > Settings > Basic Settings.



 Open the OSD menu and go to the System Setup: Advanced > Network Settings menu. Press MODE/ENTER.

- Select Remote Desktop and press MODE/ENTER
- Enter the Account and Password the same as step 1.
- Select Connect and press MODE/ENTER to connect the selected PC.
- Connect USB keyboard or mouse to control the host PC's desktop through the projector.





• Remote Desktop Control only supports LAN source so the projector source is fixed on LAN.

Presenting From a USB Reader

This fature displays a slide show of images stored on a USB flash drive connected to the projector. It can eliminate the need for a computer source.

Image File Types

USB Reader displays images files in IPEG, GIF, TIFF, PNG and BMP formats.

- A square box will display on the filename for unidentified characters.
 - · Thai filename is not supported.
 - Files in GIF, TIFF, PNG and BMP formats can be displayed for the file size smaller than WXGA (1280 x 800) only.
 - If a folder consists of more than 200 photos, only the first 200 photos can be displayed.

Preparation

To view your pictures as a slideshow, follow these steps:

- Connect a USB flash drive to your computer and copy files from your computer to the USB flash drive.
- 2. Turn on your projector if needed.
- Remove the USB flash drive from your computer and plug it into the USB TYPE-A jack of the projector.
- 4. Select **USB Reader** from the source selection bar.
- 5. Press **MODE/ENTER** to enter the thumbnail display.

USB Reader menu

The USB Reader menu will display only when USB Reader source is selected. This menu is includes with a slideshow feature for making various settings.



Main menu	Sub-menu	Options
USB Reader	Slideshow	
	Slideshow Direction	Slide Right/Slide Down
	Slideshow Timing	3 /4 /5
	Repeat Slideshow	On/Off
	Auto Rotation	On/Off
	Best Fit	On/Off


Shutting down the projector

- I. Press (1) **POWER** or **OFF** and a confirmation message will appear prompting you.
 - If you don't respond in a few seconds, the message will disappear.
- 2. Press () POWER or OFF a second time. The POWER indicator light flashes orange, the projection lamp shuts down, and the fans will continue to run for approximately 90 seconds to cool down the projector.
- To protect the lamp, the projector will not respond to any commands during the cooling process. To shorten the cooling time, you can also activate the Quick Cooling function. See "Quick Cooling" on page 75 for details.
 - Once the cooling process finishes, a "Power Off Ring Tone" will be heard. The POWER indicator light is a steady orange and fans stop. Disconnect the power cord from the power outlet.
- To turn off the power ring tone, see "Turning off the Power on/off ring tone" on page 47 for details.

If the projector is not properly shut down, to protect the

- lamp, when you attempt to re-start the projector, the fans
 will run for a few minutes to cool down. Press POWER or N again to start the projector
- after the fans stop and the **POWER indicator light** turns orange.

 Lamp life results will vary depending on environmental conditions and usage.



Menu operation

Menu system

Please note that the on-screen display (OSD) menus vary according to the signal type selected.

Main menu	Sub-menu		Options
	Wall color		Off/Light Yellow/Pink/Light Green/ Blue/Blackboard
	Aspect Ratio		Auto/Real/4:3/16:9/16:10
	Keystone (available	e in SH915)	
	2D Keystone (avail	able in SW916)	
	Due to for 3	BD content the 2D keyst	cone will be change to 1D V-keystone only.
	Corner Fit (available in SW916)		Top Left/Top Right/Bottom Left/ Bottom Right
	Surface Fit (available in SW916)		Horizontal Surface Fit/Vertical Surface Fit
	Position		
I.	Phase		
Display	H.size		
	Digital zoom		PC:1.0X~2.0X; Video: 1.0X~1.8X
	3D	3D mode	Auto/Off/Frame sequential/Frame packing/Top bottom/Side by side
		3D Sync Invert	Disable/Invert
		Save 3D Setting	3D Settings 1/3D Settings 2/3D Settings 3
		Apply 3D Setting	3D Settings 1/3D Settings 2/3D Settings 3
	T 1: T 1:	Blackboard	Off/Letter Formation/Worksheet/ Coordinate Chart
	Teaching Template	Whiteboard	Off/Letter Formation/Worksheet/ Coordinate Chart

Main menu	Sub-menu		Options
	Picture Mode		Dynamic/Presentation/sRGB/ Cinema/3D/User 1/User 2
	Reference Mode		Dynamic/Presentation/sRGB/ Cinema/3D
	Brightness		
	Contrast		
	Color		
	Tint		
	Sharpness		
2.	Brilliant Color		On/Off
Picture	Color Temperature		Cool/Normal/Warm
	Color Temperature Fine Tuning		R Gain/G Gain/B Gain/R Offset/ G Offset/B Offset
		Primary Color	R/G/B/C/M/Y
	3D Color	Hue	
	Management	Saturation	
		Gain	
	Reset picture settings		Current/All/Cancel
3.	Quick Auto Search	1	On/Off
Source	Color Space Conversion		Auto/RGB/YUV

Main menu	Sub-menu		Options
		Timer Period	I~240 min
		Timer Display	Always/I min/2mins/3 mins/Never
	Presentation Timer	Timer Position	Top-Left/Bottom-Left/Top-Right/ Bottom-Right
		Timer Counting Direction	Count Down/Count up
		Sound Reminder	On/Off
		On	Yes/No
		Off	Yes/No
	Language		English/Français/Deutsch/ Italiano/Español/Pyccкий/ 繁體中文/简体中文/日本語/한국어/ Svenska/Nederlands/Türkçe/ Čeština/Português/ Ἰոտ/Polski/ Magyar/ Hrvatski/Română/ Norsk/Dansk/Български/Suomi/ Indonesian/Ελληνικά/ألعربية/हिन्दी
4.	Projector		Front Table/Rear Table/Rear
4. System Setup: Basic	Installation		Celling/Front Ceiling
	Menu Setting	Menu display Time	5 sec/10 sec/20 sec/30 sec/Always
		Menu Position	Center/Top-Left/Top-Right/ Bottom-Right/Bottom-Left
		Reminder Message	On/Off
	0 6	Direct Power On	On/Off
		Signal Power On	On/Off
		Auto Power Off	Disable/3 mins/10 mins/15 mins/ 20 mins/25 mins/30 mins
		Quick Cooling	On/Off
	Operation Setting	Instant Restart	On/Off
		Blank Timer	Disable/5 mins/10 mins/15 mins/ 20 mins/25 mins/30 mins
		Sleep Timer	Disable/30 mins/1 hr/2 hrs/3hrs/ 4hrs/8 hrs/12hrs
	Remote Receiver		Front+Rear / Front / Rear
	Panel Key Lock		On/Off
	Background Color		BenQ / Black / Blue / Purple
	Splash Screen		BenQ / Black / Blue

Main menu	Sub-menu		Options
	High Altitude Mode		On/Off
		Mute	On/Off
	Audio Settings	Volume	
		Power on/off Ring	YES/NO
		Lamp Mode	Normal/Economic/SmartEco
	Lamp Settings	Reset Lamp Timer	Yes/No
	Lamp Secongs	Equivalent Lamp Hour	
		Change Passward	
5. System Setup: Advanced	Security Setting	Change Security Settings	
		Power On Lock	On/Off
		Web Control Lock	On/Off
	Baud Rate		2400/4800/9600/19200/38400/ 57600/1152000
	Test Pattern		On/Off
	Closed Caption	Closed Caption Enable	On/Off
		Caption Version	CC1 / CC2 / CC3 / CC4
		Network	On/Off
		Monitor Out	On/Off
	Standby Settings	Audio Pass Through	Off/Computer I/Computer 2/ Video, Svideo/HDMI I/HDMI 2/ Network Display/USB Display

Main menu	Sub-menu		Options
			Status
			DHCP
			IP Address
		Wired LAN	Subnet Mask
			Default Gateway
			DNS Server
			Apply
			Status
			SSID
		Wireless LAN	SSID Display
5.		vvireiess LAIN	IP Adress
System	Network settings		Connection Mode
Setup:	received in securings		Apply
Advanced		Remote Desktop	Account
Advanced			Password
			Connect
		Projection Login Code	On/Off
			Broadcasting
		Broadcasting	Channel
			IP Address
		AMX Device Discovery	On/Off
		Mac Address	
	Reset All Settings		Reset / Cancel
			 Source Picture Mode Lamp Mode
6.	Current System		Resolution
Information	Status		• 3D Format
			Color System
			Equivalent LampFirmware Version
			• riimware version

Note that the menu items are available when the projector detects at least one valid signal. If there is no equipment connected to the projector or no signal detected, limited menu items are accessible.

Description of each menu

	FUNCTION	DESCRIPTION		
	Wall color	Corrects the projected picture's color when the projection surface is not white. See "Using Wall Color" on page 40 for details.		
	Aspect Ratio	There are several options to set the image's aspect ratio depending on your input signal source. See "Selecting the aspect ratio" on page 38 for details.		
	Keystone	Corrects any keystoning of the image manually. See "Correcting keystone" on page 28 for details. The function is only available for SH915.		
	2D Keystone	Adjusts the shape of the projected image to ensure straight lines on all four corners. See "Correcting 2D Keystone" on page 29 for details. • The function is only available for SW916. • Due to for 3D content the 2D keystone will be change to ID V-keystone only.		
I. Displ	Corner Fit	Adjusts the shape of the projected image to ensure a specific corner is straight. See "Correcting Corner Fit" on page 30 for details. The function is only available for SW916.		
I. Display menu	Surface Fit	Calibrates the shape of the projected image to fit into the selected surface. See "Correcting Surface Fit" on page 31 for details. The function is only available for SW916.		
	Position	Displays the position adjustment page. To move the projected image, use the directional arrow keys. The values shown on the lower position of the page change with every key press you made until they reach their maximum or minimum.		
		This function is only available when a PC signal (analog RGB) is selected.		
	Phase	Adjusts the clock phase to reduce image distortion. This function is only available when a PC signal (analog RGB) is selected.		
	H.size	Adjusts the horizontal width of the image. This function is only available when a PC signal (analog RGB) is selected.		
	Digital zoom	Magnifies or reduces the projected image. See "Magnifying and searching for details" on page 38 for details.		

	FUNCTION	DESCRIPTION
	: 	This projector features a 3D function which enables you to enjoy the 3D movies, videos, and sporting events in a more realistic way by presenting the depth of the images. You need to wear a pair of 3D glasses to view the 3D images.
		3D Mode
		The default setting is Auto and the projector automatically chooses an appropriate 3D format when detecting 3D contents. If the projector cannot recognize the 3D format, press ◀/▶ to choose a 3D mode.
		When the 3D function is on:
		The brightness level of the projected image will decrease.
-		The following settings cannot be adjusted: Picture Mode, Reference Mode.
Dis	3D	The Keystone can only be adjusted within limited degrees.
pla	f S	3D Sync Invert
I. Display menu		When you discover the inversion of the image depth, enable this function to correct the problem.
Ë		Save 3D Settings
		When you have successfully displayed the 3D contents after making the appropriate adjustments, you can enable this function and choose a set of 3D settings to memorize current 3D settings.
		Apply 3D Settings
		After the 3D settings are saved, you can decide if you would like to apply them by choosing a set of 3D settings that you have saved. Once applied, the projector will automatically play the incoming 3D contents if it matches the 3D settings saved.
		Only the set(s) of 3D settings with memorized data is available.
	Teaching Template	See "Using the teaching templates" on page 48 for details.

	FUNCTION	DESCRIPTION			
	Picture Mode	Pre-defined picture modes are provided so you can optimize your projector image set-up to suit your program type. See "Selecting a picture mode" on page 40 for details.			
	Reference Mode	Selects a picture mode that most suits your need for the image quality and further fine-tune the image based on the selections listed on the same page below. See "Setting the User I/User 2 mode" on page 40 for details.			
	Brightness	Adjusts the brightness of the image. See "Adjusting Brightness" on page 41 for details.			
	Contrast	Adjusts the degree of difference between dark and light in the image. See "Adjusting Contrast" on page 41 for details.			
	Color	Adjusts the color saturation level the amount of each color in a video image. See "Adjusting Color" on page 41 for details. The function is only available when Video or S-Video with NTSC system			
2. Pict	Tint	is selected. Adjusts the red and green color tones of the image. See "Adjusting Tint" on page 41 for details. The function is only available when Video or S-Video with NTSC system is selected.			
2. Picture menu	Sharpness	Adjusts the image to make it look sharper or softer. See "Adjusting Sharpness" on page 41 for details. The function is only available when Video or S-Video with NTSC system is selected.			
	Brilliant Color	Adjusts white peaking while maintaining correct color presentation. See "Adjusting Brilliant Color" on page 41 for details.			
	Color Temperature	See "Selecting a Color Temperature" on page 41 for details.			
	Color Temperature Fine Tuning	See "Setting a preferred color temperature" on page 42 for details.			
	3D Color Management	See "3D Color Management" on page 42 for details.			
	Reset picture settings	See "Resetting current or all picture modes" on page 43 for details			
3. Sou	Quick Auto Search	See "Switching input signal" on page 37 for details.			
3. Source menu	Color Space Conversion	See "Changing Color Space" on page 37 for details.			

Operation 73

	FUNCTION	DESCRIPTION		
4.	Presentation Timer	Reminds the presenter to finish the presentation within a certain time frame. See "Setting the presentation timer" on page 43 for details.		
System	Language	Sets the language for the On-Screen Display (OSD) menus. See "Using the menus" on page 33 for details.		
etup:	Projector Installation	The projector can be installed on a ceiling or behind a screen, or with one or more mirrors. See "Choosing a location" on page 20 for details.		
		Menu display time Sets the length of time the OSD will remain active after your last key press. The range is from 5 to 30 seconds in 5-second increments.		
Basic menu	Menu Setting	Menu Position Sets the On-Screen Display (OSD) menu position.		
		Reminder Message Selecting On allows the projector to remind you to clean the filter.		

	FUNCTION	DESCRIPTION	
		Direct Power On	
		Powers projector on automatically when the power cable is connected.	
		Signal Power On	
		Sets whether to turn the projector directly on without pressing POWER or ON when the projector is in standby mode and the signal is feed through the VGA cable.	
		Auto Power Off	
		Allows the projector to turn off automatically if no input signal is detected after a set period of time. See "Setting Auto Power Off" on page 80 for details.	
		Quick Cooling	
4. Sy	Operation Setting	Enables or disables the Quick Cooling function. Selecting On enables the function and the projector cooling time will be shortened from a normal 90 second duration to approximately 2 seconds.	
tem (If you attempt to restart the projector right after the quick cooling process, it may not be turned on successfully and will rerun its cooling fans.	
Set		Instant Restart	
up: B		Selecting On enables you to restart the projector immediately within 90 seconds after turning it off.	
asi.		Blank Timer	
4. System Setup: Basic menu		Sets the image blank time when the Blank feature is activated, once elapsed the image will return to the screen. See "Hiding the image" on page 45 for details.	
_		Sleep Timer	
		Sets the auto-shutdown timer. The timer can be set to a value between 30 minutes and 12 hours.	
	Remote Receiver	Sets the preferred remote receiver (Front and Rear) allowing the projector to accept signals from the remote control.	
	Panel Key Lock	Disables or enables all panel key functions except (1) POWER on the projector and keys on the remote control. See "Locking control keys" on page 45 for details.	
	Background Color	Selects background appearance when there is no signal.	
	Splash Screen	Allows you to select which logo screen will appear during projector start-up	

Operation 75

	High Altitude		
	Mode	A mode for operation in high altitude areas. See "Operating in a high altitude environment" on page 46 for details.	
	Audio Settings	See "Adjusting the sound" on page 46 for details.	
		Lamp Mode See "Setting Lamp mode as Economic or SmartEco" on page 80 for details.	
	Lamp Settings	Reset lamp timer See "Resetting the lamp timer" on page 84 for details. Equivalent Lamp Hour See "Getting to know the lamp hour" on page 80 for details on how the total lamp hour is calculated.	
5. Syster		Change password You will be asked to enter the current password before changing to a new one. See "Utilizing the password function" on page 34 for details.	
5. System Setup: Advanced menu	Security Setting	Change Security Settings Power On Lock When Power On Lock is activated, you will be asked to enter the current password before powering on the projector.	
\dvan		If you enter incorrect password 5 times in succession, the projector will automatically shut down in a short time.	
ced		Web Control Lock See BenQ Network Projector Operation Guide for details.	
menu	Baud Rate	Selects a baud rate that is identical with your computer's so that you can connect the projector using a suitable RS-232 cable and update or download the projector's firmware. This function is intended for qualified service personnel.	
	Test Pattern	Selecting On enables the function and the projector displays the gritest pattern. It helps you adjust the image size and focus and check that the projected image is free from distortion.	
	Closed Caption	 Closed Caption Enable Activates the function by selecting On when the selected input sign carries closed captions. • Captions: An on-screen display of the dialogue, narration, and sound effects of TV programs and videos that are closed captioned (usually marked as "CC" in TV listings). Caption Version Selects a preferred closed captioning mode. To view captions, select CCI, CC2, CC3, or CC4 (CCI displays captions in the primary 	

	FUNCTION	DESCRIPTION	
		Network Selecting On enables the function. The projector is able to provide the network function when it is in standby mode.	
	Standby Settings	Monitor Out Selecting On enables the function. The projector can output a VGA signal when it is in standby mode and the COMPUTER I jack is correctly connected to devices. See "Connection" on page 23 for how to make the connection.	
	S ection 83	Audio Pass Through	
5.		The projector can play sound when it is in standby mode and the corresponding jacks are correctly connected to devices. Press ◀/▶ to choose the source that you wish to use. See "Connection" on page 23 for how to make the connection.	
Syst		Enabling this function slightly increases the standby power consumption.	
en		Wired LAN	
ո Set		See "Controlling the projector through a LAN environment" on page 49 for details.	
ä		Wireless LAN	
5. System Setup: Advanced menu	Network settings	See "Controlling the projector through a LAN environment" on page 49 for details.	
ano		Remote Desktop	
ed		See "Displaying image through Q Presenter" on page 58 for details.	
3		Projection Login Code	
ent		See "Using the Projection Login Code" on page 61 for details.	
_		Broadcasting	
		See "Using the broadcassting function" on page 62 for details.	
		AMX Device Discovery	
		When AMX Device Discovery is On , the projector can be detected by AMX controller.	
		MAC Address	
		Displays the mac address for this projector.	
	Reset All	Returns all settings to the factory preset values.	
	Settings	The following settings will still remain: Position, Phase, H. Size, Projector Installation, Language, High Altitude Mode, Security Settings, Baud Rate.	

Operation 77

	FUNCTION	DESCRIPTION
	Current System Status	Source Shows the current signal source. Picture Mode Shows the selected mode in the Picture menu.
6. In		Lamp Mode Shows the current lamp mode.
6. Information menu		Resolution Shows the native resolution of the input signal.
tion n		3D Format Shows the current 3D mode.
menu		Color System Shows input system format, NTSC, PAL, SECAM or RGB.
		Equivalent Lamp Hour Displays the number of hours the lamp has been used.
		Firmware Version Displays the firmware version of the projector.

The **Information** menu shows you the current operating status of the projector.

Maintenance

Care of the projector

Your projector needs little maintenance. The only thing you need to do on a regular basis is to keep the lens clean.

Never remove any parts of the projector except the lamp. Contact your dealer if other parts need replacing.

Cleaning the lens

Clean the lens whenever you notice dirt or dust on the surface.

- Use a canister of compressed air to remove dust.
- If there is dirt or smears, use lens-cleaning paper or moisten a soft cloth with lens cleaner and gently wipe the lens surface.



Never use any type of abrasive pad, alkaline/acid cleaner, scouring powder, or volatile solvent, such as alcohol, benzene, thinner or insecticide. Using such materials or maintaining prolonged contact with rubber or vinyl materials may result in damage to the projector surface and cabinet material.

Cleaning the projector case

Before you clean the case, turn the projector off using the proper shutdown procedure as described in "Shutting down the projector" on page 65 and unplug the power cord.

- To remove dirt or dust, wipe the case with a soft, lint-free cloth.
- To remove stubborn dirt or stains, moisten a soft cloth with water and a neutral pH detergent. Then wipe the case.



Never use wax, alcohol, benzene, thinner or other chemical detergents. These can damage the case.

Storing the projector

If you need to store the projector for an extended time, please follow the instructions below:

- Make sure the temperature and humidity of the storage area are within the recommended range for the projector. Please refer to "Specifications" on page 87 or consult your dealer about the range.
- Retract the adjuster feet.
- Remove the battery from the remote control.
- Pack the projector in its original packing or equivalent.

Transporting the projector

It is recommended that you ship the projector with its original packing or equivalent. When you carry the projector yourself, please use the original box or a suitable soft carry

Lamp information

Getting to know the lamp hour

When the projector is in operation, the duration (in hours) of lamp usage is automatically calculated by the built-in timer. The method of calculating the equivalent lamp hour is as follows:

See "Setting Lamp mode as Economic or SmartEco" below for more information on **Economic** mode.

To obtain the lamp hour information:

- Press MENU/EXIT and then press ◄/► until the SYSTEM SETUP: Advanced menu is highlighted.
- Press ▼ to highlight Lamp Settings and press MODE/ENTER. The Lamp Settings page displays.
- 3. You will see the **Equivalent lamp hour** information displaying on the menu.
- To leave the menu, press MENU/EXIT.

You can also get the lamp hour information on the INFORMATION menu.

Extending lamp life

The projection lamp is a consumable item. To keep the lamp life as long as possible, you can do the following settings via the OSD menu.

Setting Lamp mode as Economic or SmartEco

Using **Economic** mode reduces system noise and power consumption by 30%. Using **SmartEco** mode reduces system noise and lamp power consumption by up to 70%. If the **Economic** or **SmartEco** mode is selected, the light output will be reduced and result in darker projected pictures.

Setting the projector in **Economic** or **SmartEco** mode also extends the lamp operation life. To set **Economic** or **SmartEco** mode, go into the **SYSTEM SETUP:** Advanced > **Lamp Settings** > **Lamp mode** menu and press ◀/▶ until your desired mode is selected.

Lamp mode	Description
Normal	100% lamp brightness
Economic	Saves 30% lamp power consumption. (available in SH915) Saves 20% lamp power consumption. (available in SW916)
SmartEco	Saves up to 70% lamp power consumption depending on the content brightness level. (available in SH915) Save up to 50% lamp power consumption depending on the content brightness level. (available in SW916)

Setting Auto Power Off

This function allows the projector to turn off automatically if no input source is detected after a set period of time to prevent unnecessary waste of lamp life.

To set **Auto Power Off**, go into the **SYSTEM SETUP: Basic > Auto Power Off** menu and press **◄/►**. The time period can be set from 5 to 30 minutes in 5-minute increments. If the preset time lengths are not suitable for your presentation, select **Disable**. The projector will not automatically shut down in a certain time period.

Timing of replacing the lamp

When the Lamp indicator lights up red or a message appears suggesting it is time to replace the lamp, please install a new lamp or consult your dealer. An old lamp may cause a malfunction in the projector and in some instances the lamp may explode.


Go to http://lamp.beng.com for a replacement lamp.



The Lamp indicator light and Temperature warning light will light up if the lamp becomes too hot. Turn the projector off and let the projector cool for 45 minutes. If the lamp or Temp indicator still lights up after turning the power back on, please contact your dealer. See "Indicators" on page 85 for details.

The following lamp warning displays will remind you to change the lamp.


The warning messages below are for reference only. Please follow the actual on-screen instructions to prepare and replace the lamp.



Replacing the lamp




- If lamp replacement is performed while the projector is suspended upside-down from the ceiling, make sure that no one is underneath the lamp socket to avoid any possible injury or damage to the human eyes caused by fractured lamp.
- To reduce the risk of electrical shock, always turn the projector off and disconnect the power cord before changing the lamp.
- To reduce the risk of severe burns, allow the projector to cool for at least 45 minutes before replacing the lamp.
- To reduce the risk of injuries to fingers and damage to internal components, use caution when removing lamp glass that has shattered into sharp pieces.
- To reduce the risk of injuries to fingers and/or compromising image quality by touching the lens, do not
 touch the empty lamp compartment when the lamp is removed.
- This lamp contains mercury. Consult your local hazardous waste regulations to dispose of this lamp in a proper manner.
- To assure optimal performance from the projector, it is recommended that you purchase a BenQ projector lamp for lamp replacement.
- Ensure good ventilation when handling broken lamps. We recommend that you use respirators, safety glasses, goggles or face shield and wear protective clothing such as gloves.
- Turn the power off and disconnect the projector from the wall socket. If the lamp is hot, avoid burns by waiting for approximately 45 minutes until the lamp has cooled.
- Loosen the captive screw from the left side.
- Remove the lamp compartment cover as shown.



 Loosen the three captive screws that secure the lamp.



- Do not turn the power on with the lamp cover removed.
- Do not insert your fingers between the lamp and the projector. The sharp edges inside the projector may cause injuries.




 Lift the handle so that it stands up. Use the handle to slowly pull the lamp out of the projector.




- Pulling it too quickly may cause the lamp to break and scatter broken glass in the projector.
- Do not place the lamp in locations where water might splash on it, children can reach it, or near flammable materials.
- Do not insert your hands into the projector after the lamp is removed. If you touch the optical components inside, it could cause color unevenness and distortion of the projected images.
- Insert the new lamp into the lamp compartment and make sure it fits in the projector.




- · Ensure the connectors are aligned.
- If you experience resistance, lift the lamp and start again.









- Loose screw may cause a bad connection, which could result in malfunction.
- Do not over tighten the screw.











Restart the projector.



Do not turn the power on with the lamp cover removed.

Resetting the lamp timer

11. After the startup logo, open the On-Screen Display (OSD) menu. Go to the SYSTEM SETUP: Advanced > Lamp Settings menu. Press MODE/ENTER. The Lamp Settings page displays. Highlight Reset lamp timer. A warning message displays asking if you want to reset the lamp timer. Highlight Yes and press MODE/ENTER. The lamp time will be reset to '0'.



no not reset if the lamp is not new or replaced as this could cause damage.

Indicators

Light			Status & Description	
Power	Temp	Lamp		
Power e	vents			
Orange	Off	Off	Stand-by mode	
Green Flashing	Off	Off	Powering up	
Green	Off	Off	Normal operation	
Orange Flashing	Off	Off	Projector is cooling.	
Lamp e	vents			
Off	Off	Orange Flashing	The lamp ignition is not lit up.	
Off	Off	Red	 The projector needs 90 seconds to cool down. Or Please contact your dealer for assistance. 	
Therma	l events			
Red	Red	Red		The projector has shutdown
Red	Red	Off	The fans are not working.	automatically. If you try to re-start the projector, it will shutdown again. Please contact your dealer for assistance.
Red	Red	Orange	The lans are not working.	
Red	Red	Green		
Green	Orange	Off	The internal temperature is	too high
Green	Orange	Red		S .
Green	Orange	Orange		r the exhaust ventilation is blocked. a poorly ventilated location.
Green	Orange	Green	The ambient temperature	. ,
Green	Red	Red	The amount temperature may be too man.	
System events				
Green	Off	Red	The construction of the control of t	
Red Flashing	Off	Off	The projector has shutdown automatically. If you try to re-start the projector, it will shutdown again. Please contact your dealer for assistance.	
Red	Off	Red		
Off	Green	Red	Lamp door is open. Please check if the lamp door is open or not closed properly.	

Troubleshooting

? The projector does not turn on.

Cause	Remedy
There is no power from the power cable.	Plug the power cord into the AC inlet on the projector, and plug the power cord into the power outlet. If the power outlet has a switch, make sure that it is switched on.
Attempting to turn the projector on again during the cooling process.	Wait until the cooling down process has completed.

? No picture

Cause	Remedy
The video source is not turned on or connected correctly.	Turn the video source on and check that the signal cable is connected correctly.
The projector is not correctly connected to the input signal device.	Check the connection.
The input signal has not been correctly selected.	Select the correct input signal with the SOURCE key on the projector or remote control.

? Blurred image

Cause	Remedy
The projection lens is not correctly focused.	Adjust the focus of the lens using the focus ring.
The projector and the screen are not aligned properly.	Adjust the projection angle and direction as well as the height of the unit if necessary.
The lens cover is still closed.	Open the lens cover.

? Remote control does not work

Cause	Remedy
The battery is out of power.	Replace the battery with new one.
There is an obstacle between the remote control and the projector.	Remove the obstacle.
You are too far away from the projector.	Stand within 7 meters (23 feet) of the projector.

? The password is incorrect

Cause	Remedy
You do not remember the password.	Please see "Entering the password recall procedure" on page 35 for details.

Specifications

Projector specifications

All specifications are subject to change without notice.

Optical Resolution SH915 1920 x 1080 SW916 1280 x 800 Display system	Control USB Type-B MINI-B TYPE-A x 2 RS-232 serial control 9 pin x 1
Single-chip DLP™ system	IR receiver x 2
Lens F/Number	12V TRIGGER
F = 2.42 to 2.97, f = 20.7 to 31.05	12VDC (Max. 0.5 A) x 1
mm	LAN control
Lamp	RJ45 x 1
SH915	Innut torminals
310W lamp	Input terminals
SW916	Computer input
350W lamp	RGB input D-Sub 15-pin (female) x 2
Electrical	Video signal input
Power supply	S-VIDEO
AC100-240V	Mini DIN 4-pin port x 1
50-60 Hz (Automatic)	VIDEO
SH915	RCA jack x 1
3.8A	SD/HDTV signal input
SW916	Digital - HDMI x 2
4.5A	Audio signal input
Power consumption	Audio in
SH915	PC audio jack x 1
380W (Max); < 0.5W (Standby)	RCA audio jack (L/R) x 1
SW916	Environmental Requirements
450W (Max); < 0.5W (Standby)	Operating temperature
Mechanical	0°C–40°C at sea level
Weight	Operating relative humidity
8.14 lbs (3.7 Kg)	10%–90% (without condensation)
, ,	Operating altitude
Output terminals	0–1499 m at 0°C–35°C
Speaker (Mana) 5 wett v 1	1500–3000 m at 0°C–30°C (with
(Mono) 5 watt x 1	High Altitude Mode on)
Audio signal output	
PC audio jack x 1	


Specifications 87

D-Sub 15-pin (female) x1

Dimensions

360.1 mm (W) x 119.9 mm (H) x 259 mm (D)







Ceiling Mount Installation

76.0 109.0

*Ceiling Mount Screws: M4 (Max. L=25, Min. L=20)

Unit: mm





Timing chart Supported timing for PC input

Resolution	Format	Refresh rate (Hz)	H- frequency (kHz)	Pixel Frequency (MHz)
720 × 400	720 x 400_70	70.087	31.469	28.3221
	VGA_60*	59.94	31.469	25.175
640 × 480	VGA_72	72.809	37.861	31.5
640 X 480	VGA_75	75	37.5	31.5
	VGA_85	85.008	43.269	36
	SVGA_60*	60.317	37.879	40
	SVGA_72	72.188	48.077	50
800 × 600	SVGA_75	75	46.875	49.5
000 X 000	SVGA_85	85.061	53.674	56.25
	SVGA_I20** (Reduce Blanking)	119.854	77.425	83
	XGA_60*	60.004	48.363	65
	XGA_70	70.069	56.476	75
1024 x 768	XGA_75	75.029	60.023	78.75
1021 X 700	XGA_85	84.997	68.667	94.5
	XGA_120** (Reduce Blanking)	119.989	97.551	115.5
1152 x 864	1152 x 864_75	75	67.5	108
1024 × 576	BenQ Notebook Timing	60	35.82	46.966
1024 × 600	BenQ Notebook Timing	64.995	41.467	51.419
1280 x 720	1280 x 720_60*	60	45	74.25
1280 x 768	1280 x 768_60*	59.87	47.776	79.5
	WXGA_60*	59.81	49.702	83.5
1280 × 800	WXGA_75	74.934	62.795	106.5
	WXGA_85	84.88	71.554	122.5
	WXGA_120** (Reduce Blanking)	119.909	101.563	146.25
	SXGA_60***	60.02	63.981	108
1280 x 1024	SXGA_75	75.025	79.976	135
	SXGA_85	85.024	91.146	157.5

Specifications 89

Resolution	Format	Refresh rate (Hz)	H- frequency (kHz)	Pixel Frequency (MHz)
1280 × 960	1280 x 960_60***	60	60	108
1200 X 700	1280 x 960_85	85.002	85.938	148.5
1360 × 768	1360 x 768_60***	60.015	47.712	85.5
1440 × 900	WXGA+_60***	59.887	55.935	106.5
1400 x 1050	SXGA+_60***	59.978	65.317	121.75
1600 x 1200	UXGA***	60	75	162
1680 x 1050	1680 x 1050_60***	59.954	65.29	146.25
640 x 480@67Hz	MAC13	66.667	35	30.24
832 x 624@75Hz	MAC16	74.546	49.722	57.28
1024 x 768@75Hz	MAC19	74.93	60.241	80
1152 x 870@75Hz	MAC21	75.06	68.68	100

^{*} Supported timing for 3D signal with Frame Sequential, Top-Bottom and Side-by-Side format.

Support timing for Component - YPbPr input

Format	Resolution	Refresh rate (Hz)	H- frequency (kHz)	Pixel Frequency (MHz)
480i*	720 × 480	59.94	15.73	13.5
480p*	720 × 480	59.94	31.47	27
576i	720 x 576	50	15.63	13.5
576p	720 × 576	50	31.25	27
720/50p	1280 x 720	50	37.5	74.25
720/60p*	1280 × 720	60	45	74.25
1080/50i	1920 × 1080	50	28.13	74.25
1080/60i	1920 × 1080	60	33.75	74.25
1080/24 _P	1920 x 1080	24	27	74.25
1080/25p	1920 × 1080	25	28.13	74.25
1080/30 _P	1920 × 1080	30	33.75	74.25
1080/50 _P	1920 x 1080	50	56.25	148.5
1080/60 _P	1920 x 1080	60	67.5	148.5

^{*} Supported timing for 3D signal with Frame Sequential format.

^{**} Supported timing for 3D signal with Frame Sequential format.

^{****} Supported timing for 3D signal with Top-Bottom and Side-by-Side format.

The timings showing above may not be supported due to EDID file and VGA graphic card limitations. It is possible that some timings cannot be chosen.

Support timing for Video input

Format	Resolution	Refresh rate (Hz)	H- frequency (kHz)	Pixel Frequency (MHz)
NTSC*	-	60	15.73	3.58
PAL	-	50	15.63	4.43
SECAM	-	50	15.63	4.25 or 4.41
PAL-M	-	60	15.73	3.58
PAL-N	-	50	15.63	3.58
PAL-60	-	60	15.73	4.43
NTSC4.43	-	60	15.73	4.43

^{*} Supported timing for 3D signal with Frame Sequential format.

Support timing for HDMI (HDCP) input

Resolution	Format	Refresh rate (Hz)	H- frequency (kHz)	Pixel Frequency (MHz)
440 400	VGA_60*	59.94	31.469	25.175
	VGA_72	72.809	37.861	31.5
640 × 480	VGA_75	75	37.5	31.5
	VGA_85	85.008	43.269	36
720 × 400	720 × 400_70	70.087	31.469	28.3221
	SVGA_60*	60.317	37.879	40
	SVGA_72	72.188	48.077	50
800 × 600	SVGA_75	75	46.875	49.5
000 X 000	SVGA_85	85.061	53.674	56.25
	SVGA_I20** (Reduce Blanking)	119.854	77.425	83
	XGA_60*	60.004	48.363	65
	XGA_70	70.069	56.476	75
1024 x 768	XGA_75	75.029	60.023	78.75
10217700	XGA_85	84.997	68.667	94.5
	XGA_I20** (Reduce Blanking)	119.989	97.551	115.5
1152 x 864	1152 x 864_75	75	67.5	108
1024 × 576	BenQ Notebook Timing	60	35.82	46.996
1024 × 600	BenQ Notebook Timing	64.995	41.467	51.419
1280 x 720	1280 x 720_60*	60	45	74.25

Specifications 91

Resolution	Format	Refresh rate (Hz)	H- frequency (kHz)	Pixel Frequency (MHz)
1280 × 768	1280 x 768_60*	59.87	47.776	79.5
	WXGA_60*	59.81	49.702	83.5
	WXGA_75	74.934	62.795	106.5
1280 × 800	WXGA_85	84.88	71.554	122.5
	WXGA_I20** (Reduce Blanking)	119.909	101.563	146.25
	SXGA_60***	60.02	63.981	108
1280 x 1024	SXGA_75	75.025	79.976	135
	SXGA_85	85.024	91.146	157.5
1280 × 960	1280 x 960_60***	60	60	108
1280 X 960	1280 x 960_85	85.002	85.938	148.5
1360 x 768	1360 x 768_60***	60.015	47.712	85.5
1440 × 900	WXGA+_60***	59.887	55.935	106.5
1400 × 1050	SXGA+_60***	59.978	65.317	121.75
1600 x 1200	UXGA***	60	75	162
1680 × 1050	1680 x 1050_60***	59.954	65.29	146.25
640 x 480 @67Hz	MAC13	66.667	35	30.24
832 x 624 @75Hz	MAC16	74.546	49.722	57.28
1024 x 768@75Hz	MAC19	75.02	60.241	80
1152 x 870@75Hz	MAC21	75.06	68.68	100

st Supported timing for 3D signal with Frame Sequential, Top-Bottom and Side-by-Side format.

^{**} Supported timing for 3D signal with Frame Sequential format.

^{***} Supported timing for 3D signal with Top-Bottom and Side-by-Side format.

[•] The timings showing above may not be supported due to EDID file and VGA graphic card limitations. It is possible that some timings cannot be chosen.

Supporting timing for HDMI Video input

Format	Resolution	Refresh rate (Hz)	H- frequency (kHz)	Pixel Frequency (MHz)
480i***	720 (1440) x 480	59.94	15.73	27
480p***	720 x 480	59.94	31.47	27
576i	720 (1440) x 576	50	15.63	27
576p	720 × 576	50	31.25	27
720/50p**	1280 x 720	50	37.5	74.25
720/60 _P *	1280 x 720	60	45	74.25
1080/24p**	1920 x 1080	24	27	74.25
1080/25 _P	1920 x 1080	25	28.13	74.25
1080/30 _P	1920 x 1080	30	33.75	74.25
1080/50i****	1920 x 1080	50	28.13	74.25
1080/60i****	1920 x 1080	60	33.75	74.25
1080/50p*****	1920 x 1080	50	56.25	148.5
1080/60p*****	1920 x 1080	60	67.5	148.5
	1	1	1	1

st Supported timing for 3D signal with Frame Sequential, Frame Packing, Top-Bottom and Side-by-Side format.

Specifications 93

^{**} Supported timing for 3D signal with Frame Packing, Top-Bottom and Side-by-Side format.

^{***} Supported timing for 3D signal with Frame Sequential format.

^{****} Supported timing for 3D signal with Side-by-Side format.

^{*****} Supported timing for 3D signal with Top-Bottom.

Warranty and Copyright information

Limited warranty

BenQ warrants this product against any defects in material and workmanship, under normal usage and storage.

Proof of purchase date will be required with any warranty claim. In the event this product is found to be defective within the warranty period, BenQ's only obligation and your exclusive remedy shall be replacement of any defective parts (labor included). To obtain warranty service, immediately notify the dealer from which you purchased the product of any defects.

Important: The above warranty shall be void if the customer fails to operate the product in accordance with BenQ's written instructions, especially the ambient humidity must be inbetween 10% and 90%, temperature in-between 0°C and 35°C, altitude lower than 4920 feet, and avoiding to operate the projector in a dusty environment. This warranty gives you specific legal rights, and you may have other rights which vary from country to country.

For other information, please visit www.BenQ.com.

Copyright

Copyright 2011 by BenQ Corporation. All rights reserved. No part of this publication may be reproduced, transmitted, transcribed, stored in a retrieval system or translated into any language or computer language, in any form or by any means, electronic, mechanical, magnetic, optical, chemical, manual or otherwise, without the prior written permission of BenQ Corporation.

Disclaimer

BenQ Corporation makes no representations or warranties, either expressed or implied, with respect to the contents hereof and specifically disclaims any warranties, merchantability or fitness for any particular purpose. Further, BenQ Corporation reserves the right to revise this publication and to make changes from time to time in the contents hereof without obligation to notify any person of such revision or changes.

*DLP, Digital Micromirror Device and DMD are trademarks of Texas Instruments. Others are copyrights of their respective companies or organizations.